

Service Manual

High Definition Video Camera



Model No. **HC-V550P**

HC-V550PC

HC-V550PU

HC-V550EB

HC-V550EF

HC-V550EG

HC-V550EP

HC-V550EE

HC-V550GC

HC-V550GK


HC-V550GW

HC-V550MGK

HC-V550MGN

HC-V530EE

HC-V530GC



Colour

(K).....Black Type

(S).....Silver Type (only HC-V550GC/GK/V530GC)

(W).....White Type (only HC-V550EG/GC/V530GC)

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Panasonic[®]

© Panasonic Corporation 2014 Unauthorized copying and distribution is a violation of law.

TABLE OF CONTENTS


	PAGE	PAGE
1 Safety Precautions	3	
1.1. General Guidelines	3	
1.2. Leakage Current Cold Check	3	
1.3. Leakage Current Hot Check (See Figure. 1).....	3	
2 Warning	4	
2.1. Prevention of Electrostatic Discharge (ESD) to Electrostatically Sensitive (ES) Devices	4	
2.2. How to Recycle the Lithium Ion Battery (U.S. Only).....	4	
2.3. Caution for AC Cord (For EB/GC)	5	
2.4. How to Replace the Lithium Battery.....	6	
3 Service Navigation	7	
3.1. Introduction	7	
3.2. General Description About Lead Free Solder (PbF)	7	
3.3. How to Define the Model Suffix (NTSC or PAL model).....	8	
3.4. Formatting.....	9	
3.5. Baking of replacement IC and defective P.C.B.	10	
4 Specifications	11	
5 Location of Controls and Components	17	
6 Service Mode	23	
6.1. Model/Destination Settings	24	
6.2. Lock Search and Error History Indication	25	
6.3. Power ON Self Check Result Display.....	26	
6.4. Adjustment function for the Service	27	
6.5. Restore the backed up adjustment data.....	28	
6.6. Touch Panel Calibration	29	
6.7. NFC Initialization (HC-V550/V550M only)	29	
7 Service Fixture & Tools	30	
7.1. Service Fixture and Tools	30	
7.2. When Replacing the Main P.C.B.	30	
7.3. Service Position	30	
8 Disassembly and Assembly Instructions	31	
8.1. Disassembly Flow Chart for the Unit	31	
8.2. PCB Location.....	32	
8.3. Disassembly Procedure for the Unit	33	
9 Measurements and Adjustments	50	
9.1. Electric Adjustment	50	
10 Factory Setting	64	
10.1. How To Turn On The Factory Settings?.....	64	
10.2. What Is The Factory Settings?	65	
11 Block Diagram	66	
11.1. Overall Block Diagram.....	66	
11.2. Camera/System Control Circuit Block Diagram.....	67	
11.3. Video/Audio Signal Process(1) Circuit Block Diagram.....	68	
11.4. Video/Audio Signal Process(2) Circuit Block Diagram.....	69	
11.5. Lens Drive Circuit Block Diagram.....	70	
11.6. Power Supply Circuit Block Diagram.....	71	
12 Wiring Connection Diagram	72	
12.1. Interconnection Diagram	72	

1 Safety Precautions

1.1. General Guidelines

1. IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by

 in the Schematic Diagrams, Circuit Board Layout, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent X-RADIATION, shock, fire, or other hazards. Do not modify the original design without permission of manufacturer.

2. An Isolation Transformer should always be used during the servicing of AC Adaptor whose chassis is not isolated from the AC power line. Use a transformer of adequate power rating as this protects the technician from accidents resulting in personal injury from electrical shocks. It will also protect AC Adaptor from being damaged by accidental shorting that may occur during servicing.
3. When servicing, observe the original lead dress. If a short circuit is found, replace all parts which have been overheated or damaged by the short circuit.
4. After servicing, see to it that all the protective devices such as insulation barriers, insulation papers shields are properly installed.
5. After servicing, make the following leakage current checks to prevent the customer from being exposed to shock hazards.

1.2. Leakage Current Cold Check

1. Unplug the AC cord and connect a jumper between the two prongs on the plug.
2. Measure the resistance value, with an ohmmeter, between the jumpered AC plug and each exposed metallic cabinet part on the equipment such as screwheads, connectors, control shafts, etc. When the exposed metallic part has a return path to the chassis, the reading should be between $1\text{ M}\Omega$ and $5.2\text{ M}\Omega$. When the exposed metal does not have a return path to the chassis, the reading must be infinity.

1.3. Leakage Current Hot Check (See Figure. 1)

1. Plug the AC cord directly into the AC outlet. Do not use an isolation transformer for this check.
2. Connect a $1.5\text{ k}\Omega$, 10 W resistor, in parallel with a $0.15\text{ }\mu\text{F}$ capacitor, between each exposed metallic part on the set and a good earth ground, as shown in Figure. 1.
3. Use an AC voltmeter, with $1\text{ k}\Omega/\text{V}$ or more sensitivity, to measure the potential across the resistor.
4. Check each exposed metallic part, and measure the voltage at each point.
5. Reverse the AC plug in the AC outlet and repeat each of the above measurements.
6. The potential at any point should not exceed 0.75 V RMS . A leakage current tester (Simpson Model 229 or equivalent) may be used to make the hot checks, leakage current must not exceed $1/2\text{ mA}$. In case a measurement is outside of the limits specified, there is a possibility of a shock hazard, and the equipment should be repaired and rechecked before it is returned to the customer.

Hot-Check Circuit




Figure. 1

2 Warning

2.1. Prevention of Electrostatic Discharge (ESD) to Electrostatically Sensitive (ES) Devices

Some semiconductor (solid state) devices can be damaged easily by static electricity. Such components commonly are called Electrostatically Sensitive (ES) Devices. Examples of typical ES devices are integrated circuits and some field-effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by electrostatic discharge (ESD).

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any ESD on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging ESD wrist strap, which should be removed for potential shock reasons prior to applying power to the unit under test.
2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
3. Use only a grounded-tip soldering iron to solder or unsolder ES devices.
4. Use only an antistatic solder removal device. Some solder removal devices not classified as "antistatic (ESD protected)" can generate electrical charge sufficient to damage ES devices.
5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.
6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it. (Most replacement ES devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material).
7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.

CAUTION :

Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity (ESD) sufficient to damage an ES device).

2.2. How to Recycle the Lithium Ion Battery (U.S. Only)

ENGLISH



A lithium ion/polymer battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.

FRANÇAIS



L'appareil que vous vous êtes procuré est alimenté par une batterie au lithium-ion/lithium-polymère. Pour des renseignements sur le recyclage de la batterie, veuillez composer le 1-800-8-BATTERY.

2.3. Caution for AC Cord (For EB/GC)

2.3.1. Information for Your Safety

IMPORTANT

Your attention is drawn to the fact that recording of pre-recorded tapes or discs or other published or broadcast material may infringe copyright laws.

WARNING

To reduce the risk of fire or shock hazard, do not expose this equipment to rain or moisture.

CAUTION

To reduce the risk of fire or shock hazard and annoying interference, use the recommended accessories only.

FOR YOUR SAFETY

DO NOT REMOVE THE OUTER COVER

To prevent electric shock, do not remove the cover. No user serviceable parts inside. Refer servicing to qualified service personnel.

2.3.2. Caution for AC Mains Lead

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three-pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5 amperes and it is approved by ASTA or BSI to BS1362

Check for the ASTA mark or the BSI mark on the body of the fuse.



If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover, the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

If the fitted moulded plug is unsuitable for the socket outlet in your home then the fuse should be removed and the plug cut off and disposed of safely.

There is a danger of severe electrical shock if the cut off plug is inserted into any 13-ampere socket.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt, please consult a qualified electrician.

2.3.2.1. Important

The wires in this mains lead are coloured in accordance with the following code:

Blue	Neutral
Brown	Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.


The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstances should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol.




2.3.2.2. Before Use

Remove the Connector Cover as follows.




2.3.2.3. How to Replace the Fuse

1. Remove the Fuse Cover with a screwdriver.



2. Replace the fuse and attach the Fuse cover.




2.4. How to Replace the Lithium Battery

2.4.1. Replacement Procedure

1. Remove the MONITOR P.C.B.. (Refer to Disassembly Procedures.)
2. Unsolder the each soldering point of electric lead terminal for Lithium battery (Ref. No. "B501" at foil side of MONITOR P.C.B.) and remove the Lithium battery together with electric lead terminal. Then replace it into new one.

NOTE:

The Type No. ML-614S/DN includes electric lead terminals.



NOTE:

This Lithium battery is a critical component.

(Type No.: ML-614S/DN **Manufactured by Energy Company, Panasonic Corporation**)

It must never be subjected to excessive heat or discharge.

It must therefore only be fitted in requirement designed specifically for its use.

Replacement batteries must be of same type and manufacture.

They must be fitted in the same manner and location as the original battery, with the correct polarity contacts observed.

Do not attempt to re-charge the old battery or re-use it for any other purpose.

It should be disposed of in waste products destined for burial rather than incineration.

(For English)

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose of used batteries according to the manufacturer's instructions.

(For German)

ACHTUNG

Explosionsgefahr bei falschem Anbringen der Batterie. Ersetzen Sie nur mit einem äquivalentem vom Hersteller empfohlenem Typ.

Behandeln Sie gebrauchte Batterien nach den Anweisungen des Herstellers.

(For French)

MISE EN GARDE

Une batterie de remplacement inappropriée peut exploser. Ne remplacez qu'avec une batterie identique ou d'un type recommandé par le fabricant. L'élimination des batteries usées doit être faite conformément aux instructions du fabricant.

NOTE:

Above caution is applicable for a battery pack which is for HC-V550/V550M/V530 series, as well.

3 Service Navigation

3.1. Introduction

This service manual contains technical information, which allow service personnel's to understand and service this model. Please place orders using the parts list and not the drawing reference numbers. If the circuit is changed or modified, the information will be followed by service manual to be controlled with original service manual.

3.2. General Description About Lead Free Solder (PbF)

The lead free solder has been used in the mounting process of all electrical components on the printed circuit boards used for this equipment in considering the globally environmental conservation.

The normal solder is the alloy of tin (Sn) and lead (Pb). On the other hand, the lead free solder is the alloy mainly consists of tin (Sn), silver (Ag) and Copper (Cu), and the melting point of the lead free solder is higher approx.30°C (86°F) more than that of the normal solder.

Distinction of P.C.B. Lead Free Solder being used

The letter of "PbF" is printed either foil side or components side on the P.C.B. using the lead free solder.(See right figure)	PbF
--	------------

Service caution for repair work using Lead Free Solder (PbF)

- The lead free solder has to be used when repairing the equipment for which the lead free solder is used. (Definition: The letter of "PbF" is printed on the P.C.B. using the lead free solder.)
- To put lead free solder, it should be well molten and mixed with the original lead free solder.
- Remove the remaining lead free solder on the P.C.B. cleanly for soldering of the new IC.
- Since the melting point of the lead free solder is higher than that of the normal lead solder, it takes the longer time to melt the lead free solder.
- Use the soldering iron (more than 70W) equipped with the temperature control after setting the temperature at 350±30°C (662±86°F).

Recommended Lead Free Solder (Service Parts Route.)

- The following 3 types of lead free solder are available through the service parts route.
 - RFKZ03D01KS-----(0.3mm 100g Reel)
 - RFKZ06D01KS-----(0.6mm 100g Reel)
 - RFKZ10D01KS-----(1.0mm 100g Reel)

Note

* Ingredient: tin (Sn) 96.5%, silver (Ag) 3.0%, Copper (Cu) 0.5%, Cobalt (Co) / Germanium (Ge) 0.1 to 0.3%

3.3. How to Define the Model Suffix (NTSC or PAL model)

There are nine kinds of HC-V550/V550M/V530.


- a) HC-V550M (Japan domestic model)
- b) HC-V550P
- c) HC-V550PC
- d) HC-V550EB/EF/EG/EP
- e) HC-V550EE
- f) HC-V530EE
- g) HC-V550GK, V550MGK
- h) HC-V550MGN
- i) HC-V550PU/GW, V530GC

What is the difference is that the "INITIAL SETTING" data which is stored in Flash ROM mounted on Main P.C.B..


3.3.1. Defining methods:

To define the model suffix to be serviced, refer to the rating label and caution label which are putted on the Unit.


a) HC-V550M (Japan domestic model)
The nameplate for this model shows the following Safety registration mark.




b) HC-V550P
The nameplate for this model shows the following Safety registration mark.




c) HC-V550PC
The nameplate for this model shows the following Safety registration mark.




d) HC-V550EB/EF/EG/EP
The nameplate for these models show the following Safety registration mark.




e) HC-V550EE
The nameplate for this model shows the following Safety registration mark.




f) HC-V530EE
The nameplate for this model shows the following Safety registration mark.



g) HC-V550GK, V550MGK
The nameplate for these models show the following Safety registration mark.



h) HC-V550MGN
The nameplate for this model shows the following Safety registration mark.



i) HC-V550PU/GC/GW, V530GC
The nameplate for these models does not show any above Safety registration mark.

NOTE:

After replacing the MAIN P.C.B., be sure to achieve adjustment.

3.4. Formatting

The following formatting is for HC-V550/V530/V250/V230GC, V550/V250/V230GW, V550M/V250/V230GN. The page number in this page does not show the page number of this service manual.

[FORMAT MEDIA]

Please be aware that if a medium is formatted, then all the data recorded on the medium will be erased and cannot be restored. Back up important data on a PC, DVD disc etc. (→ 174)

MENU : [SETUP] → [FORMAT MEDIA] → desired media

[Built-inMemory]^{*1}/[SD CARD]/[HDD]^{*2}

*1 [HC-V550M] only.

*2 Displayed when connecting a USB HDD. (→ 115)

- [HC-V550]/[HC-V530]/[HC-V250]/[HC-V230]
Media selection screen is not displayed when the USB HDD is not connected. Touch [YES].
- When formatting is complete, touch [EXIT] to exit the message screen.
- Perform a physical formatting of the SD card when the SD card is to be disposed/ transferred. (→ 202)
- [HC-V550M]
Perform a physical formatting of the built-in memory when this unit is to be disposed/ transferred. (→ 200)

- Do not turn this unit off or remove the SD card, while formatting. Do not expose the unit to vibrations or shock.

Use this unit to format media.

Formatting built-in memory is only available with this unit.


Do not format an SD card using any other equipment such as a PC. The card may not be used on this unit.

When disposing of or giving away the SD card, note that:

- Formatting and deletion of data on this unit or computer only changes the file management information and does not completely delete the data in the SD card.
- It is recommended that the SD card is physically destroyed or the SD card is physically formatted using this unit when disposing of or giving away the SD card.


[HC-V550]/[HC-V530]/[HC-V250]/
[HC-V230]

To physically format the SD card, connect the unit via the AC adaptor, select [SETUP] → [FORMAT MEDIA] → [YES] from the menu, and then press and hold the recording start/stop button on the screen below for about 3 seconds. When the SD card data deletion screen appears, select [YES], and then follow the on-screen instructions.



[HC-V550M]

To physically format the SD card, connect the unit via the AC adaptor, select [SETUP] → [FORMAT MEDIA] → [SD CARD] from the menu, and then press and hold the recording start/stop button on the screen below for about 3 seconds. When the SD card data deletion screen appears, select [YES], and then follow the on-screen instructions.




- The customer is responsible for the management of the data in the SD card.

[HC-V550M]

When disposing of or giving away this unit, note that:

- Formatting and deletion simply change the file management information and cannot be used to completely erase the data in built-in memory of this unit. The data can be recovered using commercially available software or the like.
- We recommend that you physically format the built-in memory before disposing of or giving away this unit.

To physically format the built-in memory, connect the unit via the AC adaptor, select [SETUP] → [FORMAT MEDIA] → [Built-inMemory] from the menu, and then press and hold the recording start/stop button on the screen below for about 3 seconds. When the built-in memory data deletion screen appears, select [YES], and then follow the on-screen instructions.



- Please look after the data in your built-in memory carefully. Panasonic will not be held responsible in the unlikely case that private data is divulged.

3.5. Baking of replacement IC and defective P.C.B.


When replacing the CSP/BGA/QFN type IC mounted on the P.C.B., the problem of IC crack or foil pattern breaking in the P.C.B. might sometimes occur by rapid heating.

In order to improve the success rate of IC replacement for repair, it would be required to work out baking of replacement IC and defective P.C.B. before replacing IC.

Please refer the way of baking as follows.

Replacement IC and defective P.C.B. must be put in the heater together.

- Baking temperature and time (Hour)
80°C / 24 hour



4 Specifications

The following specification is for HV-V550/V530/V250/V230GC, V550/V250/V230GW, V550M/V250/V230GN.
Some specifications may differ depending on model suffix.

The page number in this chapter does not show the page number of this service manual.

High Definition Video Camera

Information for your safety

Power source:

DC 5.0 V (When using AC adaptor)
DC 3.6 V (When using battery)

Power consumption:

Recording;
[HC-V550] / [HC-V550M] / [HC-V530]
4.9 W
[HC-V250] / [HC-V230]
4.7 W
Charging; 7.7 W

Motion picture recording format:

[AVCHD];
AVCHD format version 2.0 compliant (AVCHD Progressive)
[MP4/iFrame];
MPEG-4 AVC file format compliant (.MP4)

Motion picture compression:

MPEG-4 AVC/H.264

Audio compression:

[AVCHD];
Dolby® Digital/2 ch
[MP4/iFrame];
AAC/2 ch

Recording mode and transfer rate:

[AVCHD]

[1080/50p];
Maximum 28 Mbps (VBR)
[PH];
Maximum 24 Mbps (VBR)
[HA];
Average 17 Mbps (VBR)
[HG];
Average 13 Mbps (VBR)
[HE];
Average 5 Mbps (VBR)

[MP4/iFrame]

[1080];
Maximum 28 Mbps (VBR)
[720];
Average 9 Mbps (VBR)
[iFrame];
Maximum 28 Mbps (VBR)
Refer to the operating instructions (PDF format) for the picture size and recordable time of a motion picture.

Still picture recording format:

JPEG (Design rule for Camera File system, based on Exif 2.2 standard)
Refer to the operating instructions (PDF format) for picture size of a still picture and number of recordable pictures.

Recording media:

SD Memory Card
SDHC Memory Card
SDXC Memory Card
Refer to the operating instructions (PDF format) for details on SD cards usable in this unit.

[HC-V550M]

Built-in memory; 16 GB

Image sensor:

1/5.8 type (1/5.8") 1MOS image sensor
Total; 2510 K
Effective pixels;
Motion picture; 2200 K (16:9)*
Still picture;
2200 K (16:9), 1700 K (4:3), 1670 K (3:2)

Lens:

Auto Iris, 50× optical zoom, F1.8 to F4.2
Focal length;
2.06 mm to 103 mm
Macro (Full range AF)
35 mm equivalent;
Motion picture;
28.0 mm to 1740 mm (16:9)*
Still picture;
28.0 mm to 1740 mm (16:9),
34.0 mm to 1766 mm (4:3),
33.6 mm to 1714 mm (3:2)
Minimum focus distance;
Normal; Approx. 2.0 cm (Wide)/
Approx. 2.2 m (Tele)
Tele Macro; Approx. 1.1 m (Tele)
Intelligent Auto Macro;
Approx. 1.0 cm (Wide)/Approx. 1.1 m (Tele)

Zoom:

i.Zoom OFF 62×*, 90× i.Zoom, 150×/3000×
digital zoom
(Using image sensor effective area)

* **HC-V550** / **HC-V550M** / **HC-V530**
When [O.I.S.] is set to [Standard] and Level
Shot Function is set to off.
HC-V250 / **HC-V230**
When [O.I.S.] is set to [Standard].

Image stabilizer function:

HC-V550 / **HC-V550M** / **HC-V530**
Optical (Hybrid Optical Image Stabilizer, Active
Mode (Rotation correction), Optical Image
Stabilizer Lock, Level Shot Function)
HC-V250 / **HC-V230**
Optical (Active Mode, Optical Image Stabilizer
Lock)

Creative Control:

[Miniature Effect]/[Silent movie]/[8mm movie]/
[Time Lapse Rec]

Monitor:

HC-V550 / **HC-V550M** / **HC-V530**
7.5 cm (3.0") wide LCD monitor (Approx. 460 K
dots)
HC-V250 / **HC-V230**
6.7 cm (2.7") wide LCD monitor (Approx. 230 K
dots)

Microphone:

Stereo (with a Zoom Microphone)

Minimum required illumination:

Approx. 4 lx (1/25 with Low Light Mode in the
Scene Mode)

Approx. 1 lx with the Night Mode function

AV connector video output level:

1.0 Vp-p, 75 Ω, PAL system

HDMI mini connector video output level:

HDMI™ (x.v.Colour™) 1080p/1080i/576p

AV connector audio output level (Line):

251 mV, 600 Ω, 2 ch

HDMI mini connector audio output level:

[AVCHD];

Dolby Digital/Linear PCM

[iFrame], [MP4];

Linear PCM

USB:

Reader function

SD card; Read only (No copyright protection
support)

HC-V550M

Built-in memory; Read only

Hi-Speed USB (USB 2.0), USB terminal Type
micro AB

USB host function (for USB HDD)

Battery charging function (Charges from USB
terminal when the main unit is off)

Dimensions:

HC-V550 / **HC-V550M** / **HC-V530**

53 mm (W)×61 mm (H)×116 mm (D)

(including projecting parts)

HC-V250 / **HC-V230**

53 mm (W)×59 mm (H)×116 mm (D)

(including projecting parts)

Mass:**HC-V550**

Approx. 235 g
[without battery (supplied) and an SD card (optional)]

HC-V550M

Approx. 237 g
[without battery (supplied)]

HC-V530

Approx. 226 g
[without battery (supplied) and an SD card (optional)]

HC-V250

Approx. 216 g
[without battery (supplied) and an SD card (optional)]

HC-V230

Approx. 211 g
[without battery (supplied) and an SD card (optional)]

Mass in operation:**HC-V550**

Approx. 280 g
[with battery (supplied) and an SD card (optional)]

HC-V550M

Approx. 280 g
[with battery (supplied)]

HC-V530

Approx. 271 g
[with battery (supplied) and an SD card (optional)]

HC-V250

Approx. 261 g
[with battery (supplied) and an SD card (optional)]

HC-V230

Approx. 256 g
[with battery (supplied) and an SD card (optional)]

Operating temperature:

0 °C to 40 °C

Operating humidity:

10%RH to 80%RH

Battery operation time:

See page 10

HC-V550 / HC-V550M / HC-V250**Wireless transmitter:**

Compliance standard; IEEE802.11b/g/n

Frequency range used;

Central frequency 2412 MHz to 2462 MHz [11ch]

Encryption method; Wi-Fi compliant WPA™/WPA2™/WEP

Access method; Infrastructure mode

NFC:

Compliance standard; ISO/IEC 18092 NFC-F (Passive Mode)

AC adaptor

Information for your safety

Power source:

AC 110 V to 240 V, 50/60 Hz

AC input:

0.25 A

DC output:

DC 5.0 V, 1.8 A

Dimensions:

(VSK0815N)

66.4 mm (W)×72 mm (H)×46.3 mm (D)

(VSK0815K)

66.4 mm (W)×78.8 mm (H)×31 mm (D)

(VSK0815M)

66.4 mm (W)×66.8 mm (H)×31 mm (D)

Mass:

(VSK0815N)

Approx. 70 g

(VSK0815K)

Approx. 65 g

(VSK0815M)

Approx. 62 g

Recording modes/approximate recordable time

- SD cards are only mentioned with their main memory size. The stated times are the approximate recordable times for continuous recording.

Recording format		[AVCHD]				
Recording mode		[1080/50p]	[1080/50i]			
Picture size/ Frame rate		1920×1080/ 50p	[PH] 1920×1080/ 50i	[HA] 1920×1080/ 50i	[HG] 1920×1080/ 50i	[HE] 1920×1080/ 50i
SD card	4 GB	19 min	21 min	30 min	40 min	1 h 30 min
	16 GB	1 h 20 min	1 h 30 min	2 h	2 h 40 min	6 h 40 min
	64 GB	5 h 20 min	6 h	8 h 30 min	11 h	27 h 30 min
(HC-V550M) Built-in memory	16 GB	1 h 20 min	1 h 30 min	2 h	2 h 40 min	6 h 40 min

- A** Favours image quality
- B** Favours Recording time

Recording format		[MP4/iFrame]		
Recording mode		[1080]	[720]	[iFrame]
Picture size/ Frame rate		1920×1080/ 50p	1280×720/ 25p	960×540/ 25p
SD card	4 GB	19 min	1 h	19 min
	16 GB	1 h 20 min	4 h 10 min	1 h 20 min
	64 GB	5 h 20 min	16 h 50 min	5 h 20 min
(HC-V550M) Built-in memory	16 GB	1 h 20 min	4 h 10 min	1 h 20 min

- "h" is an abbreviation for hour, "min" for minute and "s" for second.
- If recording for long periods, prepare batteries for 3 or 4 times the period you wish to record for. (→ 12)
- The default setting for [REC FORMAT] is [AVCHD], and the default setting for [REC MODE] is [HG].
- Maximum continuously recordable time for one scene: 6 hours
- The recording is paused once when the recording time for one scene exceeds 6 hours, and the recording will automatically resume after a few seconds.
- The recordable time may be reduced if recording with a lot of action is recorded or recording of short scene is repeated.
- Use time in the row of 4 GB in above table as a guideline for the time that can be copied onto one DVD disc (4.7 GB).

Approximate number of recordable pictures

- SD cards are only mentioned with their main memory size. The stated number is the approximate number of recordable pictures.

Picture size		10M 4224×2376	2.1M 1920×1080	7.4M 3136×2352	0.3M 640×480	
Aspect ratio		[16:9]		[4:3]		
SD card	4 GB	600	3200	800	28000	
	16 GB	2500	12500	3300	117000	
	64 GB	10000	52000	13000	475000	
[HC-V550M] Built-in memory		16 GB	2500	12500	3300	117000

Picture size		7.7M 3408×2272	2M 1728×1152	
Aspect ratio		[3:2]		
SD card	4 GB	800	2200	
	16 GB	3200	8500	
	64 GB	13000	36000	
[HC-V550M] Built-in memory		16 GB	3200	8500

- The number of recordable pictures depends on the subject being recorded.
- Maximum number of recordable pictures that can be displayed is 9999. If the number of recordable pictures exceeds 9999, R 9999+ is displayed. The number will not change when the picture is taken until the number of recordable pictures is 9999 or less.
- The memory capacity indicated on the label of an SD card is the total of the capacity for copyright protection and management and the capacity which can be used on the unit, a PC etc.

Cards that you can use with this unit

Use SD cards conforming to Class 4 or higher of the SD Speed Class Rating* for motion picture recording.

Card type	Capacity
SD Memory Card	512 MB/1 GB/2 GB
SDHC Memory Card	4 GB/6 GB/8 GB/12 GB/16 GB/24 GB/32 GB
SDXC Memory Card	48 GB/64 GB

* SD Speed Class Rating is the speed standard regarding continuous writing. Check via the label on the card, etc. e.g.:



- Please check the latest information on the support website below.
http://panasonic.jp/support/global/cs/e_cam
(This website is in English only.)
- When using an SDHC Memory Card/SDXC Memory Card with other equipment, check the equipment is compatible with these Memory Cards.
- An Eye-Fi X2 series SD card is required to use functions related to Eye-Fi. (→ 124)
- We do not guarantee the operation of SD cards other than the ones above. Further, SD cards with a capacity of less than 32 MB cannot be used for motion picture recording.
- 4 GB or more Memory Cards that do not have the SDHC logo or 48 GB or more Memory Cards that do not have the SDXC logo are not based on SD Memory Card Specifications.

Charging and recording time

■ Charging/Recording time

- Temperature: 25 °C/humidity: 60%RH
- Charging times in parentheses are when charging from the USB terminal.


HC-V550/HC-V550M/HC-V530					
Battery model number [Voltage/Capacity (minimum)]	Charging time	Recording format	Recording mode	Maximum continuous recordable time	Actual recordable time
Supplied battery/ VW-VBT190 (optional) [3.6 V/1940 mAh]	2 h 20 min (5 h 20 min)	[AVCHD]	[1080/50p]	2 h 10 min	1 h 5 min
			[PH]	2 h 10 min	1 h 5 min
			[HA]		1 h 10 min
			[HG],[HE]	2 h 15 min	1 h 10 min
		[MP4/ iFrame]	[1080]	2 h 10 min	1 h 5 min
			[720]	2 h 35 min	1 h 20 min
[iFrame]					
VW-VBT380 (optional) [3.6 V/3880 mAh]	3 h 45 min (9 h 45 min)	[AVCHD]	[1080/50p]	4 h 30 min	2 h 20 min
			[PH],[HA], [HG]	4 h 40 min	2 h 25 min
			[HE]	4 h 45 min	
		[MP4/ iFrame]	[1080]	4 h 35 min	2 h 20 min
			[720]	5 h 25 min	2 h 50 min
			[iFrame]	5 h 30 min	

HC-V250/HC-V230					
Battery model number [Voltage/Capacity (minimum)]	Charging time	Recording format	Recording mode	Maximum continuous recordable time	Actual recordable time
Supplied battery/ VW-VBT190 (optional) [3.6 V/1940 mAh]	2 h 20 min (5 h 20 min)	[AVCHD]	[1080/50p]	2 h 10 min	1 h 5 min
			[PH],[HA], [HG]	2 h 15 min	1 h 10 min
			[HE]	2 h 20 min	
		[MP4/ iFrame]	[1080]	2 h 10 min	1 h 10 min
			[720]	2 h 40 min	1 h 20 min
			[iFrame]	2 h 45 min	1 h 25 min
VW-VBT380 (optional) [3.6 V/3880 mAh]	3 h 45 min (9 h 45 min)	[AVCHD]	[1080/50p]	4 h 30 min	2 h 20 min
			[PH]	4 h 35 min	2 h 20 min
			[HA],[HG], [HE]	4 h 40 min	2 h 25 min
		[MP4/ iFrame]	[1080]	4 h 30 min	2 h 20 min
			[720]	5 h 20 min	2 h 45 min
			[iFrame]	5 h 30 min	2 h 50 min





- "h" is an abbreviation for hour, "min" for minute and "s" for second.
- These times are approximations.
- **The indicated charging time is for when the battery has been discharged completely. Charging time and recordable time vary depending on the usage conditions such as high/low temperature.**

5 Location of Controls and Components

The following description is for HV-V550/V530/V250/V230GC, V550/V250/V230GW, V550M/V250/V230GN.
Some descriptions may differ depending on model suffix.
The page number in this chapter does not show the page number of this service manual.



- | | | | |
|----|---|----|---|
| 1 | Speaker | 12 | Tripod receptacle |
| 2 | A/V connector [AV] (→ 106, 123) | • | Attaching a tripod with a screw length of 5.5 mm or more may damage the unit. |
| 3 | Recording/playback button [] / [] (→ 17) | 13 | SD card cover (→ 15) |
| 4 | [HC-V550] / [HC-V550M] / [HC-V530]
Level Shot Function button [] (→ 42)
[HC-V250] / [HC-V230]
Optical Image Stabilizer button
[] O.I.S.] (→ 43) | 14 | Access lamp [ACCESS] (→ 15) |
| 5 | Battery release lever [BATT] (→ 10) | 15 | Card slot (→ 15) |
| 6 | Power button [] (→ 16) | | |
| 7 | HDMI mini connector [HDMI] (→ 106) | | |
| 8 | USB terminal [] (→ 115, 121, 182) | | |
| 9 | [HC-V550] / [HC-V550M] / [HC-V250]
Status indicator (→ 16, 157)
[HC-V530] / [HC-V230]
Status indicator (→ 16) | | |
| 10 | Recording start/stop button (→ 23) | | |
| 11 | Battery holder (→ 10) | | |




16 DC input terminal [DC IN] (→ 11)

- Do not use any other AC adaptors except the supplied one.

17 Shoulder strap fixture



18 Grip belt

Adjust the length of the grip belt so that it fits your hand.




- 1 Flip the belt.
- 2 Adjust the length.
- 3 Replace the belt.

19 Photoshot button [] (→ 25)

- 20 Zoom lever [W/T] (In Motion Picture Recording Mode or Still Picture Recording Mode) (→ 41)/ Thumbnail display switch [ / ] (→ 28)/ Volume lever [-VOL+] (In Playback Mode) (→ 29)**

HC-V550 / HC-V550M / HC-V530


HC-V250 / HC-V230



21 LCD monitor (Touch screen) (→ 18)




- It can open up to 90°.





- It can rotate up to 180° **A** towards the lens or 90° **B** towards the opposite direction.

HC-V550 / HC-V550M / HC-V530




22 Lens cover

- The lens cover opens in  Motion Picture Recording Mode or  Still Picture Recording Mode. (→ 17)

23 Lens


24 Internal stereo microphones

HC-V250 / HC-V230



- 25 Lens cover opening/closing switch**
When not using the unit, close the lens cover to protect the lens.
- Slide the opening/closing switch to open/close the cover.
- 26 Lens cover**
27 Lens
28 Internal stereo microphones

HC-V550 / HC-V550M / HC-V250




- 29 Wi-Fi button [Wi-Fi]**
(→ 129, 135, 138, 144, 146, 150, 165, 168)
- 30 Wi-Fi Transmitter (→ 128)**
- 31 NFC touch area [] (→ 131, 139)**

Selecting a mode

You can switch this unit between Recording Mode (Motion Picture Recording Mode/Still Picture Recording Mode) and Playback Mode by pressing the recording/playback button. If you touch the recording mode switching icon in Recording Mode, this unit can be switched between Motion Picture Recording Mode and Still Picture Recording Mode.

Motion Picture Recording Mode (→ 23)	Recording motion pictures.
Still Picture Recording Mode (→ 25)	Recording still pictures.
Playback Mode (→ 27, 79)	Motion picture/Still picture playback.

Switching this unit between Recording Mode and Playback Mode



Recording/playback button

Press the button to switch this unit between Recording Mode and Playback Mode.



- When you turn on this unit, it starts up in Recording Mode.

Switching this unit between Motion Picture Recording Mode and Still Picture Recording Mode

Touch the recording mode switching icon displayed on the LCD monitor (touch screen) to switch this unit between Motion Picture Recording Mode and Still Picture Recording Mode.

1 Press the recording/playback button to switch this unit to Recording Mode.

- The recording mode switching icon **A** is displayed on the screen.

	Motion Picture Recording Mode
	Still Picture Recording Mode



(Motion Picture Recording Mode)

2 Touch the recording mode switching icon.

- Refer to page 18 for touch screen operation.

To display the recording mode switching icon

Display of the recording mode switching icon will disappear when no touch operation is performed for a specific period of time. To display it again, touch the screen.

- If the recording start/stop button is pressed in Still Picture Recording Mode or Playback Mode, this unit will be switched to Motion Picture Recording Mode. During motion picture/still picture playback or in other conditions, even if the recording start/stop button is pressed, the recording mode may not be switched.


How to use the touch screen

You can operate by directly touching the LCD monitor (touch screen) with your finger.

■ Touch


Touch and release the touch screen to select icon or picture.

- Touch the centre of the icon.
- Touching the touch screen will not operate while you are touching another part of the touch screen.



■ Slide while touching

Move your finger while pressing on the touch screen.



■ About the operation icons



Touch when changing a page or performing settings.



Touch to return to the previous screen.




About the Touch Menu

Touch ◀ (left side)/▶ (right side) of  on the Touch Menu to switch the operation icons.


- It is also possible to switch the operation icons by sliding the Touch Menu right or left while touching it.

A Touch Menu



Recording Mode

Playback Mode



B You can change the operation icons to display. (→ 36)


C Displayed only in Intelligent Auto Plus Mode (→ 47) and [Miniature Effect]/[8mm movie]/[Silent movie] of the Creative Control Mode (→ 47).

D Displayed only in [Time Lapse Rec] of the Creative Control Mode (→ 47), Scene Mode (→ 51), Endless Loop Recording Mode (→ 53), Stop Motion Animation Assist Mode* (→ 54) and Manual Mode (→ 55).

* [HC-V550]/[HC-V550M]/[HC-V530] only

■ To display the Touch Menu




Display of the Touch Menu will disappear when no touch operation is performed for a specific period of time during recording of motion picture/still picture. To display it again, touch .

- Do not touch on the LCD monitor with hard pointed tips, such as ball point pens.

6 Service Mode

Indication method of the service menu

1. Keep pressing the “Power” button, “Zoom lever” to W side and “Recording/Playback” button for more than 3 seconds until the top screen of the Service Mode Menu being displayed.



Service mode menu

Screen display	Contents	Function
1	Factory settings	Function to throw a product up in a factory shipment state.
2	Model/Destination settings	Change the Model/Destination. (Selectable models and destinations are displayed.)
4	Lock search history indication	Display the camera system error cord for three histories saved in EEPROM.
5	Power ON self check result display	Power ON self check (function to diagnose correct function of the device and interface between devices) result display.
14	Adjustment function for the service	The service adjustment do setup and adjustment of the following items required in the field service.
15	Restore the backed up adjustment data	Restore the adjustment data to new or repaired Main P.C.B. from SD card that the data backed up from original Main P.C.B. before repairs or replacement.
16	Touch panel calibration	Calibrate the touch positions of the touch panel.
17	NFC initialization (HC-V550/V550M only)	Performs the Initialization of the NFC chip and erase the settings like as Wi-Fi connection etc..

NOTE:


Do not using service mode except above table of Service mode menu.

2. End method of the top screen of the service mode menu
Touch the [EXIT] of LCD to end the service mode, and then POWER OFF.

6.1. Model/Destination Settings

Touch the [2] of LCD, select model/destination settings.

Operation specifications



Function description

- Change the Model/Destination

Display the lists of model/destination which the unit can be changed, if a shipment setup is finished. Therefore in some cases, the model/destination that is currently set is only displayed.


End method of operation

- Touch the [SET] of LCD to exit the mode/destination settings, and then POWER OFF.

6.2. Lock Search and Error History Indication

Touch the [4] of LCD, select Lock search and error history indication.

Operation specifications



Indication contents

- Lock search history indication
Display the camera system error cord for three histories saved in EEPROM.
- The error cord contents which are displayed

Error code	Description	Problematic Parts
51	Focus control is abnormal	FOCUS STEPPING MOTOR / LENS UNIT
52	Zoom control is abnormal	2ND STEPPING MOTOR / LENS UNIT
53	OIS lens control is abnormal	LENS UNIT
54	Zoom control is abnormal (2)	3RD STEPPING MOTOR / LENS UNIT
71	Lens barrier open/close is abnormal	BARRIER MOTOR UNIT / LENS FRAME UNIT


End method of operation

- Touch the [BAK] of LCD to exit the lock search and error history indication, and then POWER OFF.

6.3. Power ON Self Check Result Display

Touch the [5] of LCD, select Power ON self check result display.

Operation specifications



Indication contents

- Power ON self check result display

Function to diagnose correct function of the device and interface between devices result display.

Display the following communication test result.

- Power IC : Communication test between IC3401 and IC1503
- Main IC : DDR. Communication test between IC3401 and IC3402/IC3403
- WiFi IC : Communication test between IC3401 and Wi-Fi P.C.B.. (HC-V550/V550M only)
- NFC IC : Communication test between IC3401 and NFC P.C.B. unit. (HC-V550/V550M only)

Display other than “OK” are abnormalities of each lines.

- PanTiltter : Error display of the Remote Pan Tilt Cradle (VW-CTR1)
(When not connected the remote pan tilt cradle, display “--”.)
When error is occurred, display “NG” with the error code.

Error Code	Description
NG 01	Battery undercut
NG 04	The start-up state of the update error factor
NG 10	The failure of Tilt motor
NG 80	USB Communication Error


End method of operation

- Touch the [BAK] of LCD to exit the power on self check result display, and the POWER OFF.

6.4. Adjustment function for the Service

Touch the [14] of LCD, select the adjustment function for the service.

Operation Specifications (until before the start of the adjustment)



Function description

The service adjustment do setup and adjustment of the following items required in the field service.

For a detailed content, such as the adjustment procedure, refer to “9 Measurements and Adjustments”.

- Model setting
- Setting of the file name for adjustment data backup to SD card.
- Execution of adjustment data backup to SD card
- Checking of Switches
- Camera adjustment (Iris, Gyro, OIS and Missing pixels, Zoom hysteresis)
- Zoom Tracking adjustments
- Indoor White Balance Adjustment (CH-GAIN, PWM, WB)
- Outdoor White Balance Adjustment (PWM, WB)
- Level shot adjustment


End method of operation

- Press the power button to turn the unit off.

6.5. Restore the backed up adjustment data

Touch the [▼] of LCD, select restoring the backed up adjustment data from SD card to the unit.

Operation Specifications




Function description

Restore the adjustment data to new or repaired Main P.C.B. from SD card that the data backed up from original Main P.C.B. before repairs or replacement.

To backup the adjustment data, use “6.4. Adjustment function for the Service”.

Restoring procedure




End method of operation

- Press the power button to turn the unit off.

6.6. Touch Panel Calibration

Touch the [16] of LCD, select the calibration of touch panel.

Operation Specifications



Function description

Calibrate the touch positions of the touch panel.


End method of operation

- Press the power button to turn the unit off.

6.7. NFC Initialization (HC-V550/V550M only)

Touch the [17] of LCD, select initialization of NFC (Near Field Communication) function.

Operation Specifications



Function description

This function performs the Initialization of the NFC chip and erase the settings like as Wi-Fi connection etc..

End method of operation

- Press the power button to turn the unit off.

7 Service Fixture & Tools

7.1. Service Fixture and Tools

The following Service Fixture and tools are used for checking and servicing this unit.

Parts name	Parts No.	Remarks
Zoom Guide Shaft	VMS8231	2 use

(* When Installing the MOS Unit)

7.2. When Replacing the Main P.C.B.


After replacing the MAIN P.C.B., be sure to achieve adjustment.

7.3. Service Position

This Service Position is used for checking and replacing parts. Use the following Extension cables for servicing.

No.	Parts No.	Connection	Form
1	RFKZ0354	FP6001(MAIN) - MONITOR FPC	37PIN 0.3 FFC
2	RFKZ0444	PP6001(MAIN) - PS6401(SD HOLDER)	50PIN 0.5 B to B
3	VFK1480	FP6003(MAIN) - ECM FPC	6PIN 0.5 FFC
4	VFK1440	FP6402(SD HOLDER) - TOP OPERATION	10PIN 0.5 FFC


7.3.1. Extention Cable Connection




8 Disassembly and Assembly Instructions

8.1. Disassembly Flow Chart for the Unit

This is a disassembling chart.
When assembling, perform this chart conversely.



8.2. PCB Location



8.3. Disassembly Procedure for the Unit

No.	Item	Fig.	Removal		
1	Side Case-L Unit	(Fig. D1)	Screw (A) x 3		
			(Fig. D2)	Screw (B) x 1	
			Locking tab x 3		
			Hooking part x 3		
			Side Case-L Unit		
2	Top Case Unit, Power Panel Light, LED Piece, Jack Cover Piece, Jack Cover Spring, SS Button, SS Lever, Jack Cover Unit, Top Ornament B	(Fig. D3)	Screw (C) x 1		
			Screw (D) x 1		
			Locking tab x 3		
			Top Case Unit		
		(Fig. D4)	Power Panel Light		
			LED Piece		
			Screw (E) x 1		
			Convex x 1		
			Hooking part x 1		
			Jack Cover Piece		
			Jack Cover Spring		
			SS Button		
			SS Lever		
			Jack Cover Unit		
Top Ornament B					
3	Front Case Unit	(Fig. D5)	Screw (F) x 1		
			Screw (G) x 2		
			FP6003 (Flex)		
			Screw (H) x 1		
			Locking tab x 1		
			Convex x 2		
		(Fig. D6)	Front Case Unit		
		4	NFC P.C.B. Unit (HC-V550/V550M only)	(Fig. D7)	Screw (I) x 1
					FP6006 (Flex)
					Hooking part x 1
NFC P.C.B. Unit					
5	Wi-Fi P.C.B., (HC-V550/V550M only) ESD P.C.B. Unit (HC-V550M only)	(Fig. D8)	Flex A		
			Flex B		
			Screw (J) x 2		
			Wi-Fi P.C.B.		
			ESD P.C.B. Unit		
6	Lens Frame Unit, Heat Radiation Plate-L Unit, Barrier Motor Unit	(Fig. D9)	Screw (K) x 1		
			Screw (L) x 1		
			P6003 (Connector)		
			Screw (M) x 1		
			Convex x 2		
			Locking tab x 2		
			(Fig. D10)	FP6004 (Flex)	
		Screw (N) x 3			
		Hooking part x 2			
		Convex x 1			
		Heat Radiation Plate-L Unit			
		Boss x 3			
		Lens Frame Unit			
		Barrier Motor Unit			
7	Camera Lens Unit	(Fig. D11)	FP301 (Flex)		
			FP6008 (Flex)		
			Convex x 2		
			Camera Lens Unit		


No.	Item	Fig.	Removal
8	Main P.C.B., SD Holder P.C.B.	(Fig. D12)	Screw (O) x 1
			Screw (P) x 3
			Screw (Q) x 1
			Convex x 2
			Hooking part x 1
			Heat Radiation Plate Unit
			P6401 (Connector)
		FP6001 (Flex)	
		FP6402 (Flex)	
		(Fig. D13)	Convex x 5
			Locking tab x 4
			Bottom Frame Unit
			Main P.C.B.
SD Holder P.C.B.			
9	Top Operation, BATT. Catcher P.C.B.	(Fig. D14)	Convex x 1
			Hooking part x 1
			Locking tab x 1
			Top Operation Unit
			Hooking part x 1
			BATT. Catcher P.C.B.
10	R Frame Unit, Speaker, LCD Unit	(Fig. D15)	Screw (R) x 2
			Locking tab x 4
			R Frame Unit
			Convex x 1
		(Fig. D16)	LCD Lever
			Convex x 2
			Boss x 6
			Speaker
			Convex x 2
			LCD Unit
11	Monitor P.C.B., LCD Hinge Unit, Light Guide Plate Unit, LCD Panel	(Fig. D17)	Screw (S) x 2
			Locking tab x 9
			LCD Case (T) Unit
			Screw (T) x 1
			FP901 (Flex)
			FP904 (Flex)
			FP905 (Flex)
		(Fig. D18)	Locking tab x 1
			Hooking part x 1
			Monitor P.C.B.
			LCD Hinge Unit
			LCD Frame A
			Locking tab x 4
			Light Guide Plate Unit
LCD Panel			
(Fig. D19)	Reflection Sheet		
	Light Guide Plate		
	Diffusion Sheet		
	Prism Sheet (B)		
	Prism Sheet (A)		
	LGP Holder		
12	Front Base, Barrier R, Barrier F	(Fig. D20)	Projection part x 3
			Lens Damper Rubber
			Screw (U) x 4
			Convex x 3
			Front Base
	Barrier R		
	Barrier F		

No.	Item	Fig.	Removal
13	Front Case, Mic Cover, Front Ornament Ring, Flare Cut Piece, Microphone Unit	(Fig. D21)	Screw (V) x 2
			Locking tab x 1
			Front Case
			Mic Cover
			Front Ornament Ring
			Flare Cut Piece
			Mic Sponge-F
			Mic Sponge-M
			Microphone Unit
			Mic Sponge-R
14	MOS Unit, IR Cut Grass	(Fig. D22)	Screw (W) x 3
			MOS Unit
			MOS Cushion
			IR Cut Grass
		(Fig. D23) (Fig. D24)	NOTE: (When Installing the MOS Unit)
15	2nd Stepping Motor	(Fig. D25)	Solder x 16 points
			Screw (X) x 3
			Convex x 5
		(Fig. D26)	Screw (Y) x 2
			2nd Stepping Motor
16	3rd Stepping Motor	(Fig. D27)	Solder x 4 points
			Screw (Z) x 1
			Convex x 1
		(Fig. D28)	Screw (a) x 2
			3rd Stepping Motor
17	Focus Motor	(Fig. D29)	Solder x 8 points
			Screw (b) x 1
			Convex x 1
		(Fig. D30)	Screw (c) x 2
			Focus Motor

NOTE:


When servicing and reassembling, remove the Card and battery pack from the unit.

- Card
- Battery Pack




8.3.1. Removal of the Side Case-L Unit

- Screw (A) × 3




Screw (A)



BLACK


(Fig. D1)

- Screw (B) × 1
- Locking tab × 3
- Hooking part × 3



NOTE: (When Installing)

- Install the locking tab and hooking part of the side case-L unit in following order:
(1) → (2) → (3) → (4) → (5)




Screw (B)




BLACK

(Fig. D2)

8.3.2. Removal of the Top Case Unit, Power Panel Light, LED Piece, Jack Cover Piece, Jack Cover Spring, SS Button, SS Lever, Jack Cover Unit, Top Ornament B




(Fig. D3)




(Fig. D4)

8.3.3. Removal of the Front Case Unit




(Fig. D5)




(Fig. D6)

8.3.4. Removal of the NFC P.C.B. Unit (HC-V550/V550M only)




(Fig. D7)

8.3.5. Removal of the Wi-Fi P.C.B. (HC-V550/V550M only), ESD P.C.B. Unit (HC-V550M only)




(Fig. D8)

8.3.6. Removal of the Lens Frame Unit, Heat Radiation Plate-L Unit, Barrier Motor Unit




(Fig. D9)




(Fig. D10)

8.3.7. Removal of the Camera Lens Unit




(Fig. D11)

8.3.8. Removal of the Main P.C.B., SD Holder P.C.B.




(Fig. D12)




(Fig. D13)

8.3.9. Removal of the Top Operation, BATT. Catcher P.C.B.





(Fig. D14)


8.3.10. Removal of the R Frame Unit, Speaker, LCD Unit




(Fig. D15)

8.3.11. Removal of the Monitor P.C.B., LCD Hinge Unit, Light Guide Plate Unit, LCD Panel






(Fig. D18)




(Fig. D19)

8.3.12. Removal of the Front Base, Barrier R, Barrier F




(Fig. D20)

8.3.13. Removal of the Front Case, Mic Cover, Front Ornament Ring, Flare Cut Piece, Microphone Unit



(Fig. D21)

8.3.14. Removal of the MOS Unit, IR Cut Grass




(Fig. D22)

NOTE: (When Installing the MOS Unit)


Necessary Jig:

- Zoom Guide Shaft (VMS8231) × 2


1. Insert the two zoom guide shafts into the holes of the lens unit shown in below.



2. Insert the zoom guide shafts through the holes on the MOS fixing angle, fix the position of the MOS unit.




3. Tighten 3 screws and fix the MOS unit.



(Fig. D23)

4. Pull out both zoom guide shafts.






(Fig. D24)


8.3.15. Removal of the 2nd Stepping Motor

- Solder × 16 points
- Convex × 5
- Screw (X) × 3


- Remove the specified soldering points and remove the screw, then lift up the flex over the 2nd stepping motor.
- Do not bend the flex excessively and take care not to damage the flex.



Screw (X)




(Fig. D25)




(Fig. D26)

8.3.16. Removal of the 3rd Stepping Motor




(Fig. D27)

8.3.17. Removal of the Focus Motor




(Fig. D28)





(Fig. D29)

• Screw (c) × 2




Screw (c)



NOTE:(When Installing)

- Move the rack of focus motor to center position.
- Align the screw shaft to the rack for insertion.
- Blow air to the screw shaft of motor to prevent the adhesion of foreign material.
- Apply grease to the screw shaft of motor.

**• Grease Application Area
(Focus Motor)**



(Fig. D30)

9 Measurements and Adjustments

9.1. Electric Adjustment

- Adjustment method is different from a conventional High definition video camera.
- An exclusive jig are necessary for electric adjustment.
- Connection method of the main unit and an exclusive adjustment jig as follows.

Figure of connection





Figure of image when adjustment



Part Number of jig


1. Basic Jig

Item	Contents
AC adaptor	Banded with camcorder
AC Cable	Banded with camcorder

2. Optical Jig for Camera Adjustment

Item	Part number	Remarks
Light box	VFK1164TDVLB/RFKZ0523*	Need external power supply: 12V ± 0.1V /1.8A or over
Collimator with focus chart	VFK1164TCM02/VFK1164TCM03	Same as DSC
CC filter	3100K/5100K VFK1164CC10G	Need 2 set. For indoor/outdoor white balance adjustment
C2 Filter	5100K VFK1164LBB2	For outdoor white balance adjustment
C8 Filter	5100K VFK1164LBB8	For outdoor white balance adjustment
ND Filter 0.1	3100K VFK1164ND01	For indoor white balance adjustment
ND Filter 0.6	3100K VFK1164ND06	For indoor white balance adjustment
Adjustment chart for Level Shot	Banded with this Manual	For Level shot adjustment

* RFKZ0523 (same as DSC) is recommended.




9.1.1. About Light Box

When using VFK1164TDVLB Light Box

If using VFK1164TDVLB Light Box, remove the lens connection ring by loosening thumbscrew and three hexagon screws.

* RFKZ0523 Light Box has no lens connection ring.



How to remove the Front Hood

In order to utilize maximum of the diffusing surface of light box, some adjustment items need the distance between diffusing surface of light box and camera body becomes several centimeters.

Before the adjustments, remove the front hood of light box following steps below.



[For VFK1164TDVLB Light Box]





(1) Unscrew the 8 screws.
Slide the body case, then lift it up.

(2) Unscrew the 4 screws.

(3) Remove the front hood. Install the
body case, then tighten the 8 screws.



[For RFKZ0523 Light Box]



Unscrew the 4 screws, then remove the front hood.

9.1.2. Adjustment Items

Adjustment item as follows.

Adjustment item			Adjustments						Settings		
			Camera Adjustments ^{*1}	Zoom Tracking Adjustment	Indoor White Balance Adjustment	Outdoor White Balance Adjustment	Level Shot adjustment ^{*2}	Touch Panel Calibration	Model setting	Factory settings	NFC initialization ^{*3}
Replacement part											
MAIN P.C.B.	IC301	MOS 2.8V LDO	-	-	○	○	○	-	○	○	○
	IC701	LENS DRIVE IC	○	○	-	-	○	-	-	-	-
	IC704	GYRO 3V LDO	○	-	-	-	○	-	-	-	-
	IC751	ROLL GYRO	○	-	-	-	○	-	-	-	-
	IC1001	7CH DC/DC IC	○	○	○	○	○	-	-	-	-
	IC3401	VENUS ENGINE	-	-	-	-	○	-	-	-	-
	IC3404	FLASH ROM	○	○	○	○	○	-	○	○	○
SD HOLDER P.C.B.			○	-	-	-	○	-	-	-	-
	IC6401	PIT/YAW GYRO	○	-	-	-	○	-	-	-	-
	IC6411	ACCELEROMETER	-	-	-	-	○	-	-	-	-
ESD P.C.B. ^{*4}			-	-	-	-	○	-	-	-	-
Wi-Fi P.C.B. ^{*3}			-	-	-	-	○	-	-	○	○
NFC P.C.B. UNIT ^{*3}			-	-	-	-	○	-	-	○	○
LENS UNIT			○	○	○	○	○	-	-	-	-
MOS UNIT			○	○	○	○	○	-	-	-	-
LCD CASE (B) UNIT			-	-	-	-	○	○	-	-	-

*1...IRIS adjustment, OIS hall amp adjustment, Missing pixels compensation, OIS gyro adjustment, AGS adjustment , Zoom hysteresis adjustment

*2...Accelerometer : Since the assembly is accompanied, always need to be adjusted.

*3...HC-V550M/V550 only

*4...HC-V550M only


9.1.3. Adjustment Procedure

All adjustments except “Touch Panel Calibration”, “Factory Setting” and “NFC Initialization” performs using “14 Adjustment function for the service” in service mode menu.


“Touch Panel Calibration” is performed using 16 of service mode menu and “Factory Setting” is performed using 1, “NFC Initialization” is performed using 17 of service mode menu. Refer to “6 Service mode” and “10 Factory Setting”.

[Execute adjustment function for service]

1. While the power is turned OFF, keep pressing the “Power” button, “Zoom lever” to W side and “Recording/Playback” button for more than 3 seconds until the top screen of the Service Mode Menu being displayed.




2. Touch the ▼ twice then touch the [14] of LCD.
3. Touch the [YES] of LCD.



[Adjustment Procedure]

Adjustments and settings are performed following order:


1. Model setting
2. Filename setting for backup to SD card
3. Backing up adjustment data to SD card
4. Checking switches
5. Camera adjustment (Iris, Gyro, OIS, Missing pixels compensation, Zoom hysteresis)
6. Zoom/tracking adjustment
7. Indoor white balance adjustment (CH GAIN, PWM, WB)
8. Outdoor white balance adjustment (PWM, WB)
9. Level shot adjustment



2. Setup Backup Filename



Touch the [SET] of LCD



- < : Move cursor 1 position left
- > : Move cursor 1 position right
- ^ : Increase 1 character (0→1→2→...)
- v : Decrease 1 character (0→Z→Y→...)
- [] : Cursor

(When skipping the setup)
Touch the [BAK] of LCD.
Backup filename: 00000000000 (Default)
or
xxxxxxxxxxx (Previously set)
(The backup filename is stored in Flash ROM.)

Touch the [SET] of LCD

For example, "ABCDE123456" as the specified backup filename;
First, a new folder (folder name is "V550" for HC-V550, "V530" for HC-V530.) is created at root folder of SD card.
Next, a new folder that is named first 5 letter of specified backup filename is created inside of model-named folder.
Then, the adjustment data backup file which filename is last 6 letter of specified backup filename is created inside of above folder.




Touch the [BAK] of LCD


Touch the [SET] of LCD

3. Backup Execution

3. Backup Execution




Touch the [SET] of LCD



Adjustment data is backed up to SD card, and its filename is the specified backup filename of "2. Setup backup filename" or previous backup filename stored in Flash ROM.

(When skipping the backup) Touch the [BAK] of LCD



Touch the [SET] of LCD



Write error occurred


Touch the [SET] of LCD

Touch the [SET] of LCD




Touch the [SET] of LCD


4. Checking Switches



< Switches arrangement >



5. Camera Adjustment



Touch the [SET] of LCD




WT : Waiting for Adjust
 RUN : Now adjusting
 OK : Normal Condition
 NG : Abnormal Condition
 -- : Excluded

(When skipping the adjustment)
 Touch the [BAK] of LCD

Adjustment Item	
LOCK	Confirmation that the lens lock has not occurred.
TEMP	(Excluded)
GYRO	Result of Gyro DC compensation.
IRIS	Result of Iris adjustment.
OIS	Result of OIS adjustment.
KIZU	Result of missing pixels compensation.
HYS	Result of zooming hysteresis compensation.
WIFI	(Excluded)
RTC	Result of the RTC working normally.
KEY	Confirmation that all switches on the unit are released.
JACK	(Excluded)
TOUCH	(Excluded)
FAN	(Excluded)
SENSOR	(Excluded)
FORMAT	(Excluded)
DTEST	(Excluded)

6. Zoom/Tracking Adjustment



■ Adjustment Conditions


- Set up the collimator with focus chart in front of the lens.
- Set up the angle of view into near the center of the test chart at the tele edge.

■ Adjustment Jig

- Collimator with focus chart.

■ Other

- The focus adjustment value always starts from initial value.
- *Supposing the adjustment after the lens replacement.



■ Adjustment Conditions

- Set up the position of light box to be fully displayed at the LCD.
- Stack two piece of CC filter and set up them in front of the lens.
- Stack ND filter (0.1) and (0.6), then set up them in front of the lens.

■ Adjustment Jig


- Light box
- CC filter x 2
- ND filter (0.1)
- ND filter (0.6)

■ Adjustment Item


CH GAIN	Channel Gain : Indoor
PWM	WB gain depend on IRIS/PWM : Indoor
WB	White Balance : Indoor

- * Too high or too low brightness causes adjustment error.
- * Check the adjustment environment.

8. WB Adjustment (Outdoor)



Touch the [SET] of LCD



Touch the [SET] of LCD

■ Adjustment Conditions

- Set up the position of light box to be fully displayed at the LCD.
- Stack two piece of CC filter and set up them in front of the lens.
- Stack C2 filter and C8 filter, then set up them in front of the lens.

■ Adjustment Jig

- Light box
- CC filter x 2
- C2 filter
- C8 filter

■ Adjustment Item

PWM	WB gain depend on IRIS/PWM : Outdoor
WB	White Balance : Outdoor

(When skipping the adjustment)
Touch the [BAK] of LCD

Touch the [SET] of LCD



Error Occurred



Normally terminated


- * Too high or too low brightness causes adjustment error.
- * Check the adjustment environment.

9. Level Shot Adjustment

9. Level Shot Adjustment



Touch the [SET] of LCD




(When skipping the adjustment)
Touch the [BAK] of LCD

Press the [Photo shot] button

■Adjustment Conditions

- Open the LCD and turn reverse, then close.
- Shot the test chart to be displayed in full screen.


Distance (between end of lens and the chart):
100mm~150mm



• Unit Installation Condition


Horizontal Tilt (ROLL) : with in $\pm 2^\circ$

Vertical Tilt (PITCH) : with in $\pm 1^\circ$



■Adjustment Jig

- Test Chart



[Chart Size]

A4

Print the test chart that white line to be 0.7mm width inside the vertical line.

[Test Angle]

Confirm that the vertical line is with in $\pm 30\%$ of the center of the screen.

Confirm that the horizontal line is displayed in both ends of screen.

[Test Chart Levelness]

Horizontal tilt (ROLL) : with in $\pm 0.1^\circ$

Horizontal tilt (YAW) : with in $\pm 5.0^\circ$

Vertical tilt (PITCH) : with in $\pm 5.0^\circ$

Touch the [SET] of LCD



Error Occurred




Normally terminated



Press the power button and turn off.
Adjustment completed.


◇Level Management by Yarn Hanging




10 Factory Setting

10.1. How To Turn On The Factory Settings?

1. While the power is turned OFF, keep pressing the “Power” button, “Zoom lever” to W side and “Recording/Playback” button for more than 3 seconds until the top screen of the Service Mode Menu being displayed.



2. Touch the [1] of LCD.
3. Touch the [YES] of LCD.
4. After few seconds “END” is displayed or “ESD NODATA” as “NG” is displayed on LCD monitor. Cutting of battery connection or AC power supply connection as a completion of the “FACTORY SETTINGS”.
(After recording at least once, even if the physical format of the build-in memory will be performed, “ESD NODATA” as “NG” is indicated, but “FACTORY SETTINGS” is completed.)



10.2. What Is The Factory Settings?


The factory settings clean up and/or refresh the following settings.

1. Setting Values of menu.
2. Clear the time and date setting.
3. Close the lens cover
4. Initialize the Wi-Fi data settings (HC-V550/V550M only)
5. Initialize the NFC data settings (HC-V550/V550M only)
6. Confirm that the data area of built-in memory is cleared. (HC-V550M only)
7. Confirm that the built-in memory capacity is correct. (HC-V550M only)
(Checking of the built-in memory mounting error.)

(HC-V550M)


If the “Factory Settings” is completed, physical format of the build-in memory is not performed, execute physical format according to the following procedure.

To physically format the built-in memory, connect the unit via the AC adaptor, select [SETUP] → [FORMAT MEDIA] → [Built-inMemory] from the menu, and then press and hold the recording start/stop button on the screen below for about 3 seconds. When the built-in memory data deletion screen appears, select [YES], and then follow the on-screen instructions.




11 Block Diagram

11.1. Overall Block Diagram




HC-V550/V550M/V530 OVERALL BLOCK DIAGRAM

11.2. Camera/System Control Circuit Block Diagram




HC-V550/V550M/V530 CAMERA/SYSTEM CONTROL CIRCUIT BLOCK DIAGRAM

11.3. Video/Audio Signal Process(1) Circuit Block Diagram




HC-V550/V550M/V530 VIDEO/AUDIO PROCESS(1) CIRCUIT BLOCK DIAGRAM

11.4. Video/Audio Signal Process(2) Circuit Block Diagram




11.5. Lens Drive Circuit Block Diagram



HC-V550/V550M/V530 LENS DRIVE CIRCUIT BLOCK DIAGRAM

11.6. Power Supply Circuit Block Diagram



HC-V550/V550M/V530 POWER SUPPLY CIRCUIT BLOCK DIAGRAM

12 Wiring Connection Diagram

12.1. Interconnection Diagram

