

# DAV-DZ275M/DZ570M/ DZ665K/DZ670M

## SERVICE MANUAL

*Russian Model*

**Ver. 1.0 2008.05**

- DAV-DZ275M/DZ570M/DZ665K/DZ670M are composed of the following models.  
As service manuals are issued for each component model, please refer to them.

### COMPONENT MODEL NAME

	DAV-DZ275M	DAV-DZ570M	DAV-DZ665K	DAV-DZ670M
DVD RECEIVER	HCD-DZ275M	HCD-DZ570M	HCD-DZ665K	HCD-DZ670M
FRONT SPEAKER	SS-TS80	SS-TS82	SS-TS82	SS-TS82
CENTER SPEAKER	SS-CT80	SS-CT80	SS-CT80	SS-CT80
SURROUND SPEAKER	SS-TS80	SS-TS80	SS-TS82	SS-TS82
SUBWOOFER	SS-WS81	SS-WS81	SS-WS85	SS-WS85

### SPECIFICATIONS

#### General

Power requirements 220 V - 240 V AC, 50/60 Hz

Power consumption

DAV-DZ275M: On: 160 W  
Standby: 0.3 W (at the  
Power Saving mode)

DAV-DZ570M/DZ665K/DZ670M: On: 170 W  
Standby: 0.3 W (at the  
Power Saving mode)

Output voltage (DIGITAL MEDIA PORT)  
(DAV-DZ570M/DZ665K/DZ670M only)  
DC 5 V

Output current (DIGITAL MEDIA PORT)  
(DAV-DZ570M/DZ665K/DZ670M only)  
700 mA

Dimensions (approx.) 430 mm × 66 mm × 385 mm  
(w/h/d) incl. projecting parts

Mass (approx.) 4.2 kg

#### Unpacking

- Front speakers (2)
- Surround speakers (2)
- Center speaker (1)
- Subwoofer (1)
- AM loop antenna (aerial) (1)
- FM wire antenna (aerial) (1)
- Speaker cords (6, red/white/green/gray/blue/purple)
- Video cord (1)
- Remote commander (remote) (1)
- R6 (size AA) batteries (2)
- Calibration mic (1)
- Foot pads (1 set)
- Posts (DZ570M: 2, DZ665K/DZ670M: 4)
- Base (DZ570M: 2, DZ665K/DZ670M: 4)
- Mounting plates (DZ570M: 2, DZ665K/DZ670M: 4)
- Post covers (DZ570M: 2, DZ665K/DZ670M: 4)
- Screws (large, with washer) (DZ570M: 4, DZ665K/DZ670M: 8)
- Screws (small) (DZ570M: 6, DZ665K/DZ670M: 12)
- Operating Instructions
- Speaker and TV connections (card)

Design and specifications are subject to change without notice.

[www.electronicsrepair.net](http://www.electronicsrepair.net)

DVD HOME THEATRE SYSTEM

9-889-134-01  
2008E04-1


**Sony Corporation**  
Audio Business Group

**SONY**®

ACCESSORIES


Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1-480-569-11		COMMANDER, STANDARD (RM-ADU009) (including BATTERY COVER) (DZ275M/DZ570M)		1	3-281-186-01	STAND PIPE (S) (DZ570M/DZ665K/DZ670M)	
1-480-574-11		COMMANDER, STANDARD (RM-ADP023) (including BATTERY COVER) (DZ665K/DZ670M)		2	X-2187-372-2	STAND BASE (S) ASSY (DZ665K/DZ670M)	
1-501-374-12		ANTENNA, LOOP (AM)		2	X-2190-504-2	STAND BASE (S) ASSY (DZ570M)	
1-542-670-11		MEASUREMENT MIC (MONO) (Calibration mic)		3	3-278-700-01	BRACKET (PIPE) (DZ570M/DZ665K/DZ670M)	
1-793-184-23		CONNECTOR (F TYPE ADAPTOR) (FM)		4	2-896-204-01	STAND CAP (DZ570M/DZ665K/DZ670M)	
1-833-579-11		CORD, CONNECTION (YELLOW 1.2m)		5	7-682-973-19	SCREW +PSW 5X10 (DZ570M/DZ665K/DZ670M)	
1-833-700-11		CORD (WITH CONNECTOR) (SPEAKER) (GREEN 3m,PURPLE 3.5m,RED/WHITE 4.5m, GRAY/BLUE 12m)		6	2-630-050-11	+BVTT 3X6 (SUMITITE) (DZ570M/DZ665K/DZ670M)	
2-639-385-01		FOOT (for SPEAKER)					
3-283-039-61		MANUAL, INSTRUCTION (RUSSIAN) (DZ275M/DZ570M)					
3-283-039-71		MANUAL, INSTRUCTION (UKRAINIAN) (DZ275M/DZ570M)					
3-285-994-61		MANUAL, INSTRUCTION (RUSSIAN) (DZ665K/DZ670M)					
3-285-994-71		MANUAL, INSTRUCTION (UKRAINIAN) (DZ665K/DZ670M)					
3-876-433-01		PLAY LIST (08 KARAOKE) (EXCEPT DZ665K)					

Post




1

Base




2

Mounting plate




3

Post cover




4

Screw (large, with washer)



5

Screw (small 3 × 6)



6