

EXR Factory Data Load (USB)

Factory Songs, Styles and User Programs are contained on the internal memory of the EXR-3, 5 and 7. This memory can be erased. Follow these steps to reload the original factory data.

Tools Needed:

1. EXR-3, 5, or 7
2. Factory Data file "32-FLASH_Songs_and_Styles-1.exe"
3. USB compatible PC running Windows 98 or greater
4. USB cable

Update Procedure:

NOTE: *Reloading the factory data will erase the current data within the keyboard. Be sure to save all necessary user data to your computer before performing this operation.*

1. Connect the EXR to your computer using a USB cable.
2. Be sure the EXR is turned on.
3. Press FUNCTION.
4. Press FAMILY Right to select "Utility"
5. After a few seconds the display will show "InitFlsh." Press YES.
6. Press YES again.
7. "Complete" will display momentarily.
8. Press the USB button.
9. When "PC<->EXR" is displayed, double click the "32-FLASH_Songs_and_Styles-1.exe" factory data file on your computer.
10. Click "OK" when the copyright window opens.
11. Click "Browse."
12. Select the "EXR_DRV" drive from the window and click "OK."
13. Click "Unzip."
14. The display of the EXR will show "WRITING."
15. Once "PC<->EXR" is displayed, eject the "EXR_DRV" drive.

Note: From My Computer, right click on the "EXR_DRV" icon and select "Eject."

16. Press EXIT.
17. Press YES.

Factory Data is now reloaded and you are free to resume normal operation.