

EXR-5 System Update Procedure

Note: Updating the EXR-5 will reset the keyboard to factory settings. Be sure to back up all important information before performing the update procedure.

Tools Need:

- EXR-5 Update Disks

Creating Update Disks:

- Copy the contents of each folder to a PC formatted floppy disk. Be sure to label each disk accordingly.

Procedure:

1. Power ON while holding FUNCTION and 2.
2. Insert Disk 1.
3. When "Ins Disk #2" is displayed, eject Disk 1 and insert Disk 2.
4. When "Complete" is displayed, eject Disk 2 and turn OFF the EXR-5.
5. Power ON while holding USER PROGRAM.