

THIS WASHING MACHINE IS EQUIPPED WITH A "SOLIDS TRAP", WHICH PREVENTS THE SOLID PARTS TO GET THROUGH THE PUMP IMPELLER. THE TRAPS IS LOCATED UPSTREAM OF THE PUMP INLET AND CAN BE CLEANED (WHEN GETS CLOGGED) VIA OPENNING THE SEALED STOPPER AT THE BOTTOM OF TUB AND AT THE BACK OF THE PUMP MOTOR HOUSING.

