



LG

Life's Good

North/Latin America
Europe/Africa
Asia/Oceania

Internal Use Only

<http://aic.lgservice.com>
<http://eic.lgservice.com>
<http://biz.lgservice.com>

LED TV


SERVICE MANUAL

CHASSIS : LD42B

MODEL : 42LB65 42LB65**-Z***
42LB650V 42LB650V-TA

CAUTION

BEFORE SERVICING THE CHASSIS,
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



CONTENTS

| | |
|----------------------------------------|-----------|
| CONTENTS | 2 |
| SAFETY PRECAUTIONS | 3 |
| SERVICING PRECAUTIONS..... | 4 |
| SPECIFICATION | 6 |
| ADJUSTMENT INSTRUCTION | 13 |
| BLOCK DIAGRAM | 21 |
| EXPLODED VIEW | 22 |
| SCHEMATIC CIRCUIT DIAGRAM | |

SAFETY PRECAUTIONS

IMPORTANT SAFETY NOTICE

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These parts are identified by \triangle in the Schematic Diagram and Exploded View.

It is essential that these special safety parts should be replaced with the same components as recommended in this manual to prevent Shock, Fire, or other Hazards.

Do not modify the original design without permission of manufacturer.

General Guidance

An **isolation Transformer should always be used** during the servicing of a receiver whose chassis is not isolated from the AC power line. Use a transformer of adequate power rating as this protects the technician from accidents resulting in personal injury from electrical shocks.

It will also protect the receiver and its components from being damaged by accidental shorts of the circuitry that may be inadvertently introduced during the service operation.

If any fuse (or Fusible Resistor) in this TV receiver is blown, replace it with the specified.

When replacing a high wattage resistor (Oxide Metal Film Resistor, over 1 W), keep the resistor 10 mm away from PCB.

Keep wires away from high voltage or high temperature parts.

Before returning the receiver to the customer,

always perform an **AC leakage current check** on the exposed metallic parts of the cabinet, such as antennas, terminals, etc., to be sure the set is safe to operate without damage of electrical shock.

Leakage Current Cold Check(Antenna Cold Check)

With the instrument AC plug removed from AC source, connect an electrical jumper across the two AC plug prongs. Place the AC switch in the on position, connect one lead of ohm-meter to the AC plug prongs tied together and touch other ohm-meter lead in turn to each exposed metallic parts such as antenna terminals, phone jacks, etc.

If the exposed metallic part has a return path to the chassis, the measured resistance should be between 1 M Ω and 5.2 M Ω .

When the exposed metal has no return path to the chassis the reading must be infinite.

An other abnormality exists that must be corrected before the receiver is returned to the customer.

Leakage Current Hot Check (See below Figure)

Plug the AC cord directly into the AC outlet.

Do not use a line Isolation Transformer during this check.


Connect 1.5 K / 10 watt resistor in parallel with a 0.15 uF capacitor between a known good earth ground (Water Pipe, Conduit, etc.) and the exposed metallic parts.

Measure the AC voltage across the resistor using AC voltmeter with 1000 ohms/volt or more sensitivity.

Reverse plug the AC cord into the AC outlet and repeat AC voltage measurements for each exposed metallic part. Any voltage measured must not exceed 0.75 volt RMS which corresponds to 0.5 mA.

In case any measurement is out of the limits specified, there is possibility of shock hazard and the set must be checked and repaired before it is returned to the customer.

Leakage Current Hot Check circuit



When 25A is impressed between Earth and 2nd Ground for 1 second, Resistance must be less than 0.1 Ω

*Base on Adjustment standard

SERVICING PRECAUTIONS

CAUTION: Before servicing receivers covered by this service manual and its supplements and addenda, read and follow the **SAFETY PRECAUTIONS** on page 3 of this publication.
NOTE: If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions on page 3 of this publication, always follow the safety precautions. Remember: Safety First.

General Servicing Precautions

1. Always unplug the receiver AC power cord from the AC power source before;
 - a. Removing or reinstalling any component, circuit board module or any other receiver assembly.
 - b. Disconnecting or reconnecting any receiver electrical plug or other electrical connection.
 - c. Connecting a test substitute in parallel with an electrolytic capacitor in the receiver.
CAUTION: A wrong part substitution or incorrect polarity installation of electrolytic capacitors may result in an explosion hazard.
2. Test high voltage only by measuring it with an appropriate high voltage meter or other voltage measuring device (DVM, FETVOM, etc) equipped with a suitable high voltage probe. Do not test high voltage by "drawing an arc".
3. Do not spray chemicals on or near this receiver or any of its assemblies.
4. Unless specified otherwise in this service manual, clean electrical contacts only by applying the following mixture to the contacts with a pipe cleaner, cotton-tipped stick or comparable non-abrasive applicator; 10 % (by volume) Acetone and 90 % (by volume) isopropyl alcohol (90 % - 99 % strength)
CAUTION: This is a flammable mixture.
Unless specified otherwise in this service manual, lubrication of contacts is not required.
5. Do not defeat any plug/socket B+ voltage interlocks with which receivers covered by this service manual might be equipped.
6. Do not apply AC power to this instrument and/or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
7. Always connect the test receiver ground lead to the receiver chassis ground before connecting the test receiver positive lead.
Always remove the test receiver ground lead last.
8. Use with this receiver only the test fixtures specified in this service manual.
CAUTION: Do not connect the test fixture ground strap to any heat sink in this receiver.

Electrostatically Sensitive (ES) Devices

Some semiconductor (solid-state) devices can be damaged easily by static electricity. Such components commonly are called Electrostatically Sensitive (ES) Devices. Examples of typical ES devices are integrated circuits and some field-effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by static by static electricity.

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed to prevent potential shock reasons prior to applying power to the unit under test.

2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
3. Use only a grounded-tip soldering iron to solder or unsolder ES devices.
4. Use only an anti-static type solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ES devices.
5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.
6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it. (Most replacement ES devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material).
7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.
CAUTION: Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.
8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ES device.)

General Soldering Guidelines

1. Use a grounded-tip, low-wattage soldering iron and appropriate tip size and shape that will maintain tip temperature within the range of 500 °F to 600 °F.
2. Use an appropriate gauge of RMA resin-core solder composed of 60 parts tin/40 parts lead.
3. Keep the soldering iron tip clean and well tinned.
4. Thoroughly clean the surfaces to be soldered. Use a mall wire-bristle (0.5 inch, or 1.25 cm) brush with a metal handle. Do not use freon-propelled spray-on cleaners.
5. Use the following unsoldering technique
 - a. Allow the soldering iron tip to reach normal temperature. (500 °F to 600 °F)
 - b. Heat the component lead until the solder melts.
 - c. Quickly draw the melted solder with an anti-static, suction-type solder removal device or with solder braid.
CAUTION: Work quickly to avoid overheating the circuit board printed foil.
6. Use the following soldering technique.
 - a. Allow the soldering iron tip to reach a normal temperature (500 °F to 600 °F)
 - b. First, hold the soldering iron tip and solder the strand against the component lead until the solder melts.
 - c. Quickly move the soldering iron tip to the junction of the component lead and the printed circuit foil, and hold it there only until the solder flows onto and around both the component lead and the foil.
CAUTION: Work quickly to avoid overheating the circuit board printed foil.
 - d. Closely inspect the solder area and remove any excess or splashed solder with a small wire-bristle brush.

IC Remove/Replacement

Some chassis circuit boards have slotted holes (oblong) through which the IC leads are inserted and then bent flat against the circuit foil. When holes are the slotted type, the following technique should be used to remove and replace the IC. When working with boards using the familiar round hole, use the standard technique as outlined in paragraphs 5 and 6 above.

Removal

1. Desolder and straighten each IC lead in one operation by gently prying up on the lead with the soldering iron tip as the solder melts.
2. Draw away the melted solder with an anti-static suction-type solder removal device (or with solder braid) before removing the IC.

Replacement

1. Carefully insert the replacement IC in the circuit board.
2. Carefully bend each IC lead against the circuit foil pad and solder it.
3. Clean the soldered areas with a small wire-bristle brush. (It is not necessary to reapply acrylic coating to the areas).

"Small-Signal" Discrete Transistor Removal/Replacement

1. Remove the defective transistor by clipping its leads as close as possible to the component body.
2. Bend into a "U" shape the end of each of three leads remaining on the circuit board.
3. Bend into a "U" shape the replacement transistor leads.
4. Connect the replacement transistor leads to the corresponding leads extending from the circuit board and crimp the "U" with long nose pliers to insure metal to metal contact then solder each connection.

Power Output, Transistor Device

Removal/Replacement

1. Heat and remove all solder from around the transistor leads.
2. Remove the heat sink mounting screw (if so equipped).
3. Carefully remove the transistor from the heat sink of the circuit board.
4. Insert new transistor in the circuit board.
5. Solder each transistor lead, and clip off excess lead.
6. Replace heat sink.

Diode Removal/Replacement

1. Remove defective diode by clipping its leads as close as possible to diode body.
2. Bend the two remaining leads perpendicular y to the circuit board.
3. Observing diode polarity, wrap each lead of the new diode around the corresponding lead on the circuit board.
4. Securely crimp each connection and solder it.
5. Inspect (on the circuit board copper side) the solder joints of the two "original" leads. If they are not shiny, reheat them and if necessary, apply additional solder.

Fuse and Conventional Resistor

Removal/Replacement

1. Clip each fuse or resistor lead at top of the circuit board hollow stake.
2. Securely crimp the leads of replacement component around notch at stake top.

3. Solder the connections.

CAUTION: Maintain original spacing between the replaced component and adjacent components and the circuit board to prevent excessive component temperatures.

Circuit Board Foil Repair

Excessive heat applied to the copper foil of any printed circuit board will weaken the adhesive that bonds the foil to the circuit board causing the foil to separate from or "lift-off" the board. The following guidelines and procedures should be followed whenever this condition is encountered.

At IC Connections

To repair a defective copper pattern at IC connections use the following procedure to install a jumper wire on the copper pattern side of the circuit board. (Use this technique only on IC connections).

1. Carefully remove the damaged copper pattern with a sharp knife. (Remove only as much copper as absolutely necessary).
2. Carefully scratch away the solder resist and acrylic coating (if used) from the end of the remaining copper pattern.
3. Bend a small "U" in one end of a small gauge jumper wire and carefully crimp it around the IC pin. Solder the IC connection.
4. Route the jumper wire along the path of the out-away copper pattern and let it overlap the previously scraped end of the good copper pattern. Solder the overlapped area and clip off any excess jumper wire.

At Other Connections

Use the following technique to repair the defective copper pattern at connections other than IC Pins. This technique involves the installation of a jumper wire on the component side of the circuit board.

1. Remove the defective copper pattern with a sharp knife. Remove at least 1/4 inch of copper, to ensure that a hazardous condition will not exist if the jumper wire opens.
2. Trace along the copper pattern from both sides of the pattern break and locate the nearest component that is directly connected to the affected copper pattern.
3. Connect insulated 20-gauge jumper wire from the lead of the nearest component on one side of the pattern break to the lead of the nearest component on the other side. Carefully crimp and solder the connections.

CAUTION: Be sure the insulated jumper wire is dressed so the it does not touch components or sharp edges.

SPECIFICATION

NOTE : Specifications and others are subject to change without notice for improvement.

1. Application range

This specification is applied to the LED TV used LD42B chassis.

2. Requirement for Test

Each part is tested as below without special appointment.

- (1) Temperature: 25 °C ± 5 °C(77 °F ± 9 °F), CST: 40 °C ± 5 °C
- (2) Relative Humidity: 65 % ± 10 %
- (3) Power Voltage
: Standard input voltage (AC 100-240 V~, 50/60 Hz)
* Standard Voltage of each products is marked by models.
- (4) Specification and performance of each parts are followed each drawing and specification by part number in accordance with BOM.
- (5) The receiver must be operated for about 20 minutes prior to the adjustment.

3. Test method

- (1) Performance: LGE TV test method followed
- (2) Demanded other specification
 - Safety : CE, IEC specification
 - EMC : CE, IEC

4. Model General Specification

| No. | Item | Specification | Remarks |
|-----|--------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | Market | EU(PAL Market-37Countries) | <p>DTV & Analog (Total 37 countries) DTV (MPEG2/4, DVB-T) : 29 countries Germany, Netherland, Switzerland, Hungary, Austria, Slovenia, Bulgaria, France, Spain, Italy, Belgium, Luxemburg, Greece, Czech, Croatia, Turkey, Morocco, Ireland, Latvia, Estonia, Lithuania, Poland, Portugal, Romania, Albania, Bosnia, Serbia, Slovakia, Beralus</p> <p>DTV (MPEG2/4, DVB-T2): 8 countries UK(Ireland), Sweden, Denmark, Finland, Norway, Ukraine, Kazakhstan, Russia</p> <p>DTV (MPEG2/4, DVB-C): 37 countries Germany, Netherland, Switzerland, Hungary, Austria, Slovenia, Bulgaria, France, Spain, Italy, Belgium, Russia, Luxemburg, Greece, Czech, Croatia, Turkey, Morocco, Ireland, Latvia, Estonia, Lithuania, Poland, Portugal, Romania, Albania, Bosnia, Serbia, Slovakia, Beralus, UK, Sweden, Denmark, Finland, Norway, Ukraine, Kazakhstan</p> <p>DTV (MPEG2/4,DVB-S): 30 countries Germany, Netherland, Switzerland, Hungary, Austria, Slovenia, Bulgaria, France, Spain, Italy, Belgium, Russia, Luxemburg, Greece, Czech, Croatia, Turkey, Morocco, Ireland, Latvia, Estonia, Lithuania, Poland, Portugal, Romania, Albania, Bosnia, Serbia, Slovakia, Beralus</p> <p>Supported satellite : 22 satellites HISPASAT 1C/1D, ATLANTIC BIRD 2, NILESAT 101/102, ATLANTIC BIRD 3, AMOS 2/3, THOR 5/6, IRIUS 4, EUTELSAT-W3A, EUROBIRD 9A, EUTELSAT-W2A, HOTBIRD 6/8/9, EUTELSAT-SESAT, ASTRA 1L/H/M/KR, ASTRA 3A/3B, BADR 4/6, ASTRA 2D, EUROBIRD 3, EUTELSAT-W7, HELLASSAT 2, EXPRESS AM1, TURK-SAT 2A/3A, INTERSAT10</p> |

| No. | Item | Specification | Remarks |
|-----|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2 | Television system | 1) Digital TV - DVB-T/T2 - DVB-C - DVB-S/S2 2) Analogue TV - PAL/SECAM B/G/I/D/K - SECAM L/L' | |
| 3 | Program coverage | 1) Digital TV - VHF, UHF - C-Band, Ku-Band 2) Analogue TV - VHF : E2 to E12 - UHF : E21 to E69 - CATV : S1 to S20 - HYPER : S21 to S47 | |
| 4 | Receiving system | Analog : Upper Heterodyne Digital : COFDM, QAM | <p>▶ DVB-T</p> <ul style="list-style-type: none"> - Guard Interval(Bitrate_Mbit/s) 1/4, 1/8, 1/16, 1/32 - Modulation : Code Rate QPSK : 1/2, 2/3, 3/4, 5/6, 7/8 16-QAM : 1/2, 2/3, 3/4, 5/6, 7/8 64-QAM : 1/2, 2/3, 3/4, 5/6, 7/8 <p>▶ DVB-T2 (Model : *L*V*-Z* (T2 only Model))</p> <ul style="list-style-type: none"> - Guard Interval(Bitrate_Mbit/s) 1/4, 1/8, 1/16, 1/32, 1/128, 19/128, 19/256, - Modulation : Code Rate QPSK : 1/2, 2/5, 2/3, 3/4, 5/6 16-QAM : 1/2, 2/5, 2/3, 3/4, 5/6 64-QAM : 1/2, 2/5, 2/3, 3/4, 5/6 256-QAM : 1/2, 2/5, 2/3, 3/4, 5/6 <p>▶ DVB-C</p> <ul style="list-style-type: none"> - Symbolrate : 4.0Msymbols/s to 7.2Msymbols/s - Modulation : 16QAM, 64-QAM, 128-QAM and 256-QAM <p>▶ DVB-S/S2</p> <ul style="list-style-type: none"> - symbolrate DVB-S2 (8PSK / QPSK) : 2 ~ 45Msymbol/s DVB-S (QPSK) : 2 ~ 45Msymbol/s - viterbi DVB-S mode : 1/2, 2/3, 3/4, 5/6, 7/8 DVB-S2 mode : 1/2, 2/3, 3/4, 3/5, 4/5, 5/6, 8/9, 9/10 |
| 5 | Scart (1EA) | PAL, SECAM | Scart 1 Jack is Full scart and support ATV/DTV-OUT (not support DTV Auto AV) |
| 6 | Video Input RCA(1EA) | PAL, SECAM, NTSC4.43 | 4 System : PAL, SECAM, NTSC4.43, PAL60 Hybrid Type |
| 7 | Head phone out | Antenna, AV1, AV2, Component, HDMI1, HDMI2, HDMI3, USB1, USB2, USB3 | |
| 8 | Component Input (1EA) | Y/Cb/Cr Y/Pb/Pr | Hybrid Type |
| 9 | HDMI Input (3EA) | HDMI1-DTV HDMI2-DTV HDMI3-DTV | HDMI1: PC support(HDMI version 1.3) Support HDCP |
| 10 | Audio Input (3EA) | DVI Audio Component/AV2 AV1 | L/R Input. |
| 11 | SDPIF out (1EA) | SPDIF out | |
| 12 | USB (1EA) | EMF, DivX HD, For SVC (download) | JPEG, MP3, DivX HD |
| 13 | Ethernet Connect(1EA) | Ethernet Connect | |
| 14 | PCMCIA Card slot (1EA) | PCMCIA slot | |

5. Component Video Input (Y, PB, PR)

| No. | Specification | | | |
|-----|---------------|-------------|------------|--------------------|
| | Resolution | H-freq(kHz) | V-freq(Hz) | Pixel clock |
| 1. | 720×480 | 15.73 | 60.00 | SDTV, DVD 480i |
| 2. | 720×480 | 15.63 | 59.94 | SDTV, DVD 480i |
| 3. | 720×480 | 31.47 | 59.94 | 480p |
| 4. | 720×480 | 31.50 | 60.00 | 480p |
| 5. | 720×576 | 15.625 | 50.00 | SDTV, DVD 625 Line |
| 6. | 720×576 | 31.25 | 50.00 | HDTV 576p |
| 7. | 1280×720 | 45.00 | 50.00 | HDTV 720p |
| 8. | 1280×720 | 44.96 | 59.94 | HDTV 720p |
| 9. | 1280×720 | 45.00 | 60.00 | HDTV 720p |
| 10. | 1920×1080 | 31.25 | 50.00 | HDTV 1080i |
| 11. | 1920×1080 | 33.75 | 60.00 | HDTV 1080i |
| 12. | 1920×1080 | 33.72 | 59.94 | HDTV 1080i |
| 13. | 1920×1080 | 56.250 | 50 | HDTV 1080p |
| 14. | 1920×1080 | 67.5 | 60 | HDTV 1080p |

6. HDMI Input

6.1. DTV mode

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) |
|-----|------------|----------------|----------------|------------------|
| 1. | 640*480 | 31.469 / 31.5 | 59.94/60 | SDTV 480P |
| 2. | 720*480 | 31.469 / 31.5 | 59.94 / 60 | SDTV 480P |
| 3. | 720*576 | 31.25 | 50 | SDTV 576P |
| 4. | 720*576 | 15.625 | 50 | SDTV 576I |
| 5. | 1280*720 | 37.500 | 50 | HDTV 720P |
| 6. | 1280*720 | 44.96 / 45 | 59.94 / 60 | HDTV 720P |
| 7. | 1920*1080 | 33.72 / 33.75 | 59.94 / 60 | HDTV 1080I |
| 8. | 1920*1080 | 28.125 | 50.00 | HDTV 1080I |
| 9. | 1920*1080 | 26.97 / 27 | 23.97 / 24 | HDTV 1080P |
| 10. | 1920*1080 | 28.125 | 25 | HDTV 1080P |
| 11. | 1920*1080 | 33.716 / 33.75 | 29.976 / 30.00 | HDTV 1080P |
| 12. | 1920*1080 | 56.250 | 50 | HDTV 1080P |
| 13. | 1920*1080 | 67.43 / 67.5 | 59.94 / 60 | HDTV 1080P |

6.2. PC mode

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) |
|-----|-------------------|-------------|-------------|-------------------------|
| 1 | 640 x 350 @70Hz | 31.468 | 70.09 | EGA |
| 2 | 720 x 400 @70Hz | 31.469 | 70.08 | DOS |
| 3 | 640 x 480 @60Hz | 31.469 | 59.94 | VESA(VGA) |
| 4 | 800 x 600 @60Hz | 37.879 | 60.31 | VESA(SVGA) |
| 5 | 1024 x 768 @60Hz | 48.363 | 60.00 | VESA(XGA) |
| 6 | 1152 x 864 @60Hz | 54.348 | 60.053 | VESA |
| 7 | 1280 x 1024 @60Hz | 63.981 | 60.020 | VESA(SXGA) |
| 8 | 1360 x 768 @60Hz | 47.712 | 60.015 | VESA(WXGA) |
| 9 | 1920 x 1080 @60Hz | 67.5 | 60.00 | WUXGA(Reduced Blanking) |

7. 3D Mode

7.1. HDMI 1.4b (3D supported mode automatically)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | VIC | 3D input proposed mode | Proposed |
|-----|----------------|----------------|---------------|------------------|--------------------------------------|----------------------------------------------|------------------------------------------------|
| 1 | 640*480 | 31.469 / 31.5 | 59.94/ 60 | 25.125 | 1 | Top-and-Bottom Side-by-side(half) | Secondary(SDTV 480P) Secondary(SDTV 480P) |
| 2 | | 62.938/63 | 59.94/ 60 | 50.35/50.4 | 1 | Frame packing Line alternative | Secondary(SDTV 480P) (SDTV 480P) |
| 3 | | 31.469 / 31.5 | 59.94/ 60 | 50.35/50.4 | 1 | Side-by-side(Full) | (SDTV 480P) |
| 4 | 720*480 | 31.469 / 31.5 | 59.94 / 60 | 27.00/27.03 | 2,3 | Top-and-Bottom Side-by-side(half) | Secondary(SDTV 480P) Secondary(SDTV 480P) |
| 5 | | 62.938/63 | 59.94 / 60 | 54/54.06 | 2,3 | Frame packing Line alternative | Secondary(SDTV 480P) (SDTV 480P) |
| 6 | | 31.469 / 31.5 | 59.94 / 60 | 54/54.06 | 2,3 | Side-by-side(Full) | (SDTV 480P) |
| 7 | 720*576 | 31.25 | 50 | 27 | 17,18 | Top-and-Bottom Side-by-side(half) | Secondary(SDTV 576P) Secondary(SDTV 576P) |
| 8 | | 62.5 | 50 | 54 | 17,18 | Frame packing Line alternative | Secondary(SDTV 576P) (SDTV 576P) |
| 9 | | 31.25 | 50 | 54 | 17,18 | Side-by-side(Full) | (SDTV 576P) |
| 10 | 1280*720 | 37.5 | 50 | 74.25 | 19 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 720P) Primary(HDTV 720P) |
| 11 | | 75 | 50 | 148.5 | 19 | Frame packing Line alternative | Primary(HDTV 720P) (HDTV 720P) |
| 12 | | 37.500 | 50 | 148.5 | 19 | Side-by-side(Full) | (HDTV 720P) |
| 13 | | 44.96 / 45 | 59.94 / 60 | 74.18/74.25 | 4 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 720P) Primary(HDTV 720P) |
| 14 | | 89.91/90 | 59.94 / 60 | 148.35/148.5 | 4 | Frame packing Line alternative | Primary(HDTV 720P) (HDTV 720P) |
| 15 | | 44.96 / 45 | 59.94 / 60 | 148.35/148.5 | 4 | Side-by-side(Full) | (HDTV 720P) |
| 16 | 1920*1080 | 33.72 / 33.75 | 59.94 / 60 | 74.18/74.25 | 5 | Top-and-Bottom Side-by-side(half) | Secondary(HDTV 1080I) Primary(HDTV 1080I) |
| 17 | | 67.432 / 67.50 | 59.94 / 60 | 148.35/148.5 | 5 | Frame packing Field alternative | Primary(HDTV 1080I) (HDTV 1080I) |
| 18 | | 33.72 / 33.75 | 59.94 / 60 | 148.35/148.5 | 5 | Side-by-side(Full) | (HDTV 1080I) |
| 19 | | 28.125 | 50.00 | 74.25 | 20 | Top-and-Bottom Side-by-side(half) | Secondary(HDTV 1080I) Primary(HDTV 1080I) |
| 20 | | 56.25 | 50.00 | 148.5 | 20 | Frame packing Field alternative | Primary(HDTV 1080I) (HDTV 1080I) |
| 21 | | 28.125 | 50.00 | 148.5 | 20 | Side-by-side(Full) | (HDTV 1080I) |
| 22 | | 26.97 / 27 | 23.97 / 24 | 74.18/74.25 | 32 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 1080P) Primary(HDTV 1080P) |
| 23 | | 43.94/54 | 23.97 / 24 | 148.35/148.5 | 32 | Frame packing Line alternative | Primary(HDTV 1080P) (HDTV 1080P) |
| 24 | | 26.97 / 27 | 23.97 / 24 | 148.35/148.5 | 32 | Side-by-side(Full) | (HDTV 1080P) |
| 25 | | 28.125 | 25 | 74.25 | 33 | Top-and-Bottom Side-by-side(half) | Secondary(HDTV 1080P) Secondary(HDTV 1080P) |
| 26 | | 56.24 | 25 | 148.5 | 33 | Frame packing Line alternative | Secondary(HDTV 1080P) (HDTV 1080P) |
| 27 | | 28.12 | 25 | 148.5 | 33 | Side-by-side(Full) | (HDTV 1080P) |
| 28 | 33.716 / 33.75 | 29.976 / 30.00 | 74.18/74.25 | 34 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 1080P) Secondary(HDTV 1080P) | |
| 29 | 67.432 / 67.5 | 29.976 / 30.00 | 148.35/148.5 | 34 | Frame packing Line alternative | Primary(HDTV 1080P) (HDTV 1080P) | |
| 30 | 33.716 / 33.75 | 29.976 / 30.00 | 148.35/148.5 | 34 | Side-by-side(Full) | (HDTV 1080P) | |
| 31 | 56.250 | 50 | 148.5 | 31 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 1080P) Secondary(HDTV 1080P) | |
| 32 | 67.43 / 67.5 | 59.94 / 60 | 148.35/148.50 | 16 | Top-and-Bottom Side-by-side(half) | Primary(HDTV 1080P) Secondary(HDTV 1080P) | |

7.2. HDMI Input(1.3)

| No. | Resolution | H-freq(kHz) | V-freq.(kHz) | Pixel clock(MHz) | Proposed | 3D input proposed mode |
|-----|------------|-------------|--------------|------------------|------------|---------------------------------------------------------------------------------------------------------------------------|
| 1 | 720*480 | 31.5 | 60 | 27.03 | SDTV 480P | 2D to 3D, Side by Side(Half), Top & Bottom, Checker Board, Frame Sequential, Row Interleaving, Column Interleaving |
| 2 | 720*576 | 31.25 | 50 | 27 | SDTV 576P | |
| 3 | 1280*720 | 45.00 | 60.00 | 74.25 | HDTV 720P | |
| 4 | 1280*720 | 37.500 | 50 | 74.25 | HDTV 720P | |
| 5 | 1920*1080 | 33.75 | 60.00 | 74.25 | HDTV 1080I | 2D to 3D, Side by Side(Half), Top & Bottom |
| 6 | 1920*1080 | 28.125 | 50.00 | 74.25 | HDTV 1080I | |
| 7 | 1920*1080 | 27.00 | 24.00 | 74.25 | HDTV 1080P | 2D to 3D, Side by Side(Half), Top & Bottom, Checker Board, Row Interleaving, Column Interleaving |
| 8 | 1920*1080 | 28.12 | 25 | 74.25 | HDTV 1080P | |
| 9 | 1920*1080 | 33.75 | 30.00 | 74.25 | HDTV 1080P | |
| 10 | 1920*1080 | 67.50 | 60.00 | 148.5 | HDTV 1080P | 2D to 3D, Side by Side(Half), Top & Bottom, Checker Board, Single Frame Sequential, Row Interleaving, Column Interleaving |
| 11 | 1920*1080 | 56.250 | 50 | 148.5 | HDTV 1080P | |

7.3. RF Input(3D supported mode manually)

| No. | Resolution | Proposed | 3D input proposed mode |
|-----|-------------------------|---------------|------------------------------------------------|
| 1 | HD | 1080I 720P | 2D to 3D Side by Side(Half) Top & Bottom |
| 2 | SD | 576P 576I | |
| 3 | SD (ATV : CVBS / SCART) | - | |

7.4. RF Input (3D supported mode automatically)

| No. | Signal | 3D input proposed mode |
|-----|------------------|----------------------------------|
| 1 | Frame Compatible | Side by Side(Half), Top & Bottom |

7.5. USB, DLNA (Movie) Input (3D supported mode manually)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | 3D input proposed mode |
|-----|--------------------------|-------------|-------------|------------------|--------------------------------------------------------------------------------------------------------------------|
| 1 | Under 704x480 | - | - | - | 2D to 3D |
| 2 | Over 704x480 interlaced | - | - | - | 2D to 3D, Side by Side(Half), Top & Bottom |
| 3 | Over 704x480 progressive | - | 50 / 60 | - | 2D to 3D, Side by Side(Half), Top & Bottom, Checker Board, Row Interleaving, Column Interleaving, Frame Sequential |
| 4 | Over 704x480 progressive | - | others | - | 2D to 3D, Side by Side(Half), Top & Bottom, Checker Board, Row Interleaving, Column Interleaving |

7.6. USB, DLNA (Photo) Input (3D supported mode manually)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | 3D input proposed mode |
|-----|---------------|-------------|-------------|------------------|--------------------------------------------|
| 1 | Under 320x240 | - | - | - | 2D to 3D |
| 2 | Over 320x240 | - | - | - | 2D to 3D, Side by Side(Half), Top & Bottom |

*** USB, DNLA Input (3D supported mode automatically)**

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | 3D input proposed mode |
|-----|------------|-------------|-------------|------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | 1080P | 33.75 | 30 | - | 2D to 3D, Side by Side(Half)*, Top & Bottom*, Checker Board*, Row Interleaving, Column Interleaving(Photo : Side by Side(Half), Top&Bottom) |

7.7. HDMI-PC Input (3D supported mode manually)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | 3D input proposed mode | Proposed |
|-----|------------|-------------|-------------|------------------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|
| 1 | 1024*768 | 48.36 | 60 | 65 | 2D to 3D, Side by Side(half) Top & Bottom | HDTV 768P |
| 2 | 1360*768 | 47.71 | 60 | 85.5 | | |
| 3 | 1920*1080 | 67.500 | 60 | 148.50 | 2D to 3D, Side by Side(half), Top & Bottom, Checker Board, Single Frame Sequential, Row Interleaving, Column Interleaving | HDTV 1080P |
| 4 | Others | - | - | - | 2D to 3D, Side by Side(half) Top & Bottom | 640*350 720*400 640*480 800*600 1152*864 |







7.8. Component Input(3D) (3D supported mode manually)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock | Proposed | 3D input proposed mode |
|-----|------------|-------------|-------------|-------------|------------|--------------------------------------------|
| 1 | 1280*720 | 45.00 | 60.00 | 74.25 | HDTV 720P | 2D to 3D, Side by Side(Half), Top & Bottom |
| 2 | 1280*720 | 37.500 | 50 | 74.25 | HDTV 720P | |
| 3 | 1920*1080 | 33.75 | 60.00 | 74.25 | HDTV 1080I | |
| 4 | 1920*1080 | 28.125 | 50.00 | 74.25 | HDTV 1080I | |
| 5 | 1920*1080 | 27.00 | 24.00 | 74.25 | HDTV 1080P | |
| 6 | 1920*1080 | 28.12 | 25 | 74.25 | HDTV 1080P | |
| 7 | 1920*1080 | 33.75 | 30.00 | 74.25 | HDTV 1080P | |
| 8 | 1920*1080 | 67.50 | 60.00 | 148.5 | HDTV 1080P | |
| 9 | 1920*1080 | 56.250 | 50 | 148.5 | HDTV 1080P | |
| 10 | Others | - | - | - | SDTV | |

7.9. Miracast, Widi (3D supported mode manually)

| No. | Resolution | H-freq(kHz) | V-freq.(Hz) | Pixel clock(MHz) | 3D input proposed mode |
|-----|------------|-------------|-------------|------------------|--------------------------------------------|
| 1 | 1024X768p | - | 30 / 60 | - | 2D to 3D, Side by Side(Half), Top & Bottom |
| 2. | 1280x720p | - | 30 / 60 | - | |
| 3 | 1920X1080p | | 30 / 60 | | |
| 4 | Others | | - | | 2D to 3D |

7.10. 3D Input mode

| No. | Side by Side | Top & Bottom | Checker board | Single Frame Sequential | Frame Packing | 2D to 3D |
|-----|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| 1 |  |  |  |  |  |  |

ADJUSTMENT INSTRUCTION

1. Application Range

This specification sheet is applied to all of the LED TV with LD42B chassis.

2. Designation

- (1) Because this is not a hot chassis, it is not necessary to use an isolation transformer. However, the use of isolation transformer will help protect test instrument.
- (2) Adjustment must be done in the correct order.
- (3) The adjustment must be performed in the circumstance of $25\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$ of temperature and $65\% \pm 10\%$ of relative humidity if there is no specific designation.
- (4) The input voltage of the receiver must keep AC 100-240 V~, 50/60 Hz.
- (5) The receiver must be operated for about 5 minutes prior to the adjustment when module is in the circumstance of over 15.

In case of keeping module is in the circumstance of $0\text{ }^{\circ}\text{C}$, it should be placed in the circumstance of above $15\text{ }^{\circ}\text{C}$ for 2 hours.

In case of keeping module is in the circumstance of below $-20\text{ }^{\circ}\text{C}$, it should be placed in the circumstance of above $15\text{ }^{\circ}\text{C}$ for 3 hours.

[Caution]

When still image is displayed for a period of 20 minutes or longer (Especially where W/B scale is strong. Digital pattern 13ch and/or Cross hatch pattern 09ch), there can some afterimage in the black level area.


3. Automatic Adjustment

3.1. MAC address D/L, CI+ key D/L, Widevine key D/L, ESN D/L, HDCP14/20 D/L, DTCP

Connect: USB port

Communication Prot connection


- Com 1,2,3,4 and 115200(Baudrate)
- Mode check: Online Only
- Check the test process: DETECT → MAC → CI → Widevine → ESN → HDCP14 → HDCP20 → DTCP
- Play: Press Enter key
- Result: Ready, Test, OK or NG
- Printer Out (MAC Address Label)



3.2. LAN Inspection



3.2.1. Equipment & Condition

- Each other connection to LAN Port of IP Hub and Jig




3.2.2. LAN inspection solution

- LAN Port connection with PCB
- Setting automatic IP




- If you want manual connection, enter Network connection at MENU Mode of TV. Press Start connection key, then Network will be connected.



- Setting state confirmation
- If automatic setting is finished, you confirm IP and MAC Address at 'in start' menu mode.

3.2.3. WIDEVINE key Inspection

- Confirm key input data at the "IN START" MENU Mode.



3.3. LAN PORT INSPECTION(PING TEST)

Connect SET → LAN port == PC → LAN Port



3.3.1. Equipment setting

- Play the LAN Port Test PROGRAM.
- Input IP set up for an inspection to Test Program.
*IP Number : 12.12.2.2

3.3.2. LAN PORT inspection(PING TEST)

- Play the LAN Port Test Program.
- Connect each other LAN Port Jack.
- Play Test (F9) button and confirm OK Message.
- Remove LAN cable.



3.4. Model name & Serial number Download

3.4.1. Model name & Serial number D/L

- Press "P-ONLY" key of service remote control.
(Baud rate : 115200 bps)
- Connect RS-232C Signal to USB Cable to USB.
- Write Serial number by use USB port.
- Must check the serial number at Instart menu.


3.4.2. Method & notice

- Serial number D/L is using of scan equipment.
- Setting of scan equipment operated by Manufacturing Technology Group.
- Serial number D/L must be conformed when it is produced in production line, because serial number D/L is mandatory by D-book 4.0.

* Manual Download (Model Name and Serial Number)

If the TV set is downloaded by OTA or service man, sometimes model name or serial number is initialized.(Not always)
It is impossible to download by bar code scan, so It need Manual download.

- Press the "Instart" key of Adjustment remote control.
- Go to the menu "7.Model Number D/L" like below photo.
- Input the Factory model name(ex 47LB650V-ZA) or Serial number like photo.



- Check the model name Instart menu. → Factory name displayed. (ex 47LB650V-ZA)
- Check the Diagnostics.(DTV country only) → Buyer model displayed. (ex 47LB650V-ZA)

3.5. CI+ Key checking method

- Check the Section 3.1

Check whether the key was downloaded or not at 'In Start' menu. (Refer to below).



=> Check the Download to CI+ Key value in LGset.

3.5.1. Check the method of CI+ Key value

- Check the method on Instart menu
- Check the method of RS232C Command

1) Into the main ass'y mode(RS232: aa 00 00)

| CMD 1 | CMD 2 | Data 0 | |
|-------|-------|--------|---|
| A | A | 0 | 0 |

2) Check the key download for transmitted command (RS232: ci 00 10)

| CMD 1 | CMD 2 | Data 0 | |
|-------|-------|--------|---|
| C | I | 1 | 0 |

3) Result value

- Normally status for download : OKx
- Abnormally status for download : NGx

3.5.2. Check the method of CI+ key value(RS232)

1) Into the main ass'y mode(RS232: aa 00 00)

| CMD 1 | CMD 2 | Data 0 | |
|-------|-------|--------|---|
| A | A | 0 | 0 |

2) Check the method of CI+ key by command (RS232: ci 00 20)

| CMD 1 | CMD 2 | Data 0 | |
|-------|-------|--------|---|
| C | I | 2 | 0 |

3) Result value

i 01 OK 1d1852d21c1ed5dcx


→ CI+ Key Value

3.6. WIFI MAC ADDRESS CHECK

(1) Using RS232 Command

| | | |
|--------------|------------------------|-------------------|
| | H-freq(kHz) | V-freq.(Hz) |
| Transmission | [A][I][Set ID][20][Cr] | [O][K][X] or [NG] |

(2) Check the menu on in-start



4. Manual Adjustment

* ADC adjustment is not needed because of OTP(Auto ADC adjustment)

4.1. EDID DATA

4.1.1. 3D EDID

| HDMI EDID DATA 3D | | | | | | | | | | | | | | | |
|-------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
| 0 | 00 | FF | FF | FF | FF | FF | 00 | 1E | 6D | | | | | | |
| 10 | | 01 | 03 | 80 | A0 | 5A | 78 | 0A | EE | 91 | A3 | 54 | 4C | 99 | 26 |
| 20 | 0F | 50 | 54 | A1 | 08 | 00 | 31 | 40 | 45 | 40 | 61 | 40 | 71 | 40 | 81 |
| 30 | 01 | 01 | 01 | 01 | 01 | 01 | 02 | 3A | 80 | 18 | 71 | 38 | 2D | 40 | 58 |
| 40 | 45 | 00 | 40 | 84 | 63 | 00 | 00 | 1E | 66 | 21 | 50 | 80 | 51 | 00 | 18 |
| 50 | 40 | 70 | 36 | 00 | 40 | 84 | 63 | 00 | 00 | 1E | 00 | 00 | 00 | FD | 00 |
| 60 | 3E | 1E | 53 | 10 | 00 | 0A | 20 | 20 | 20 | 20 | 20 | | | | |
| 70 | | | | | | | | | | | | | | 01 | 01 |
| 80 | 02 | 03 | 3A | F1 | 4E | 10 | 9F | 04 | 13 | 05 | 14 | 03 | 02 | 12 | 20 |
| 90 | 22 | 15 | 01 | 29 | 3D | 06 | C0 | 15 | 07 | 50 | 09 | 57 | 07 | | |
| A0 | | | | | | | | | | E3 | 05 | 00 | 00 | 01 | 1D |
| B0 | 20 | 58 | 2C | 25 | 00 | A0 | 5A | 00 | 00 | 00 | 9E | 01 | 1D | 00 | 80 |
| C0 | D0 | 1A | 20 | 6E | 88 | 55 | 00 | A0 | 5A | 00 | 00 | 00 | 1A | 02 | 3A |
| D0 | 18 | 71 | 38 | 2D | 40 | 58 | 2C | 45 | 00 | A0 | 5A | 00 | 00 | 00 | 1E |
| E0 | 21 | 50 | 80 | 51 | 00 | 18 | 30 | 40 | 70 | 36 | 00 | A0 | 5A | 00 | 00 |
| F0 | 1E | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |

- Reference
 - HDMI1 ~ HDMI3
 - In the data of EDID, bellows may be different by S/W or Input mode.
- Product ID

| HEX | EDID Table | DDC Function |
|------|------------|--------------|
| 0001 | 0100 | Analog |
| 0001 | 0100 | Digital |
- Serial No: Controlled on production line.
- Month, Year: Controlled on production line:
 - Monthly : '01' → '01'
 - Year : '2013' → '17'
- Model Name(Hex): LGTV

| Chassis | MODEL NAME(HEX) |
|---------|----------------------------------------------------|
| LD42B | 00 00 00 FC 00 4C 47 20 54 56 0A 20 20 20 20 20 20 |

Checksum(LG TV): Changeable by total EDID data.

| | ① | ② | ② | ③ |
|-------|----|-------------------|------------------|---|
| | | 10bit /none XvYcc | 8bit /none XvYcc | |
| HDMI1 | E7 | 85 | CC | X |
| HDMI2 | E7 | 75 | BC | X |
| HDMI3 | E7 | 65 | AC | X |

Vendor Specific(HDMI)

1) Deep color (module 10bit)

| INPUT | MODEL NAME(HEX) |
|-------|----------------------------------------------------------------------------|
| HDMI1 | 78 03 0C 00 10 00 B8 2D 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |
| HDMI2 | 78 03 0C 00 20 00 B8 2D 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |
| HDMI3 | 78 03 0C 00 30 00 B8 2D 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |

2) None deep color (module 8bit)

| INPUT | MODEL NAME(HEX) |
|-------|----------------------------------------------------------------------------|
| HDMI1 | 78 03 0C 00 10 00 80 1E 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |
| HDMI2 | 78 03 0C 00 20 00 80 1E 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |
| HDMI3 | 78 03 0C 00 30 00 80 1E 20 C0 0E 01 4F 3F FC 08 10 18 10 06 10 16 10 28 10 |

Colorimetry Data Block(HDMI)

1) The Model not supporting XvYcc

| INPUT | MODEL NAME(HEX) |
|-------|-----------------|
| HDMI1 | E3 05 00 00 |
| HDMI2 | E3 05 00 00 |
| HDMI3 | E3 05 00 00 |

4.1.2. 2D EDID

| HDMI EDID DATA 2D | | | | | | | | | | | | | | | |
|-------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
| 0 | 00 | FF | FF | FF | FF | FF | 00 | 1E | 6D | | | | | | |
| 10 | | 01 | 03 | 80 | A0 | 5A | 78 | 0A | EE | 91 | A3 | 54 | 4C | 99 | 26 |
| 20 | 0F | 50 | 54 | A1 | 08 | 00 | 31 | 40 | 45 | 40 | 61 | 40 | 71 | 40 | 81 |
| 30 | 01 | 01 | 01 | 01 | 01 | 01 | 02 | 3A | 80 | 18 | 71 | 38 | 2D | 40 | 58 |
| 40 | 45 | 00 | 40 | 84 | 63 | 00 | 00 | 1E | 66 | 21 | 50 | 80 | 51 | 00 | 18 |
| 50 | 40 | 70 | 36 | 00 | 40 | 84 | 63 | 00 | 00 | 1E | 00 | 00 | 00 | FD | 00 |
| 60 | 3E | 1E | 53 | 10 | 00 | 0A | 20 | 20 | 20 | 20 | 20 | | | | |
| 70 | | | | | | | | | | | | | | 01 | 01 |
| 80 | 02 | 03 | 3A | F1 | 4E | 10 | 9F | 04 | 13 | 05 | 14 | 03 | 02 | 12 | 20 |
| 90 | 22 | 15 | 01 | 29 | 3D | 06 | C0 | 15 | 07 | 50 | 09 | 57 | 07 | | |
| A0 | | | | | | | | | | E3 | 05 | 00 | 00 | 01 | 1D |
| B0 | 20 | 58 | 2C | 25 | 00 | A0 | 5A | 00 | 00 | 00 | 9E | 01 | 1D | 00 | 80 |
| C0 | D0 | 1A | 20 | 6E | 88 | 55 | 00 | A0 | 5A | 00 | 00 | 00 | 1A | 02 | 3A |
| D0 | 18 | 71 | 38 | 2D | 40 | 58 | 2C | 45 | 00 | A0 | 5A | 00 | 00 | 00 | 1E |
| E0 | 21 | 50 | 80 | 51 | 00 | 18 | 30 | 40 | 70 | 36 | 00 | A0 | 5A | 00 | 00 |
| F0 | 1E | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |

- Reference
 - HDMI1 ~ HDMI3
 - In the data of EDID, bellows may be different by S/W or Input mode.
- Product ID

| HEX | EDID Table | DDC Function |
|------|------------|--------------|
| 0001 | 0100 | Analog |
| 0001 | 0100 | Digital |
- Serial No: Controlled on production line.
- Month, Year: Controlled on production line:
 - Monthly : '01' → '01'
 - Year : '2013' → '17'
- Model Name(Hex): LGTV

| Chassis | MODEL NAME(HEX) |
|---------|----------------------------------------------------|
| LD33B | 00 00 00 FC 00 4C 47 20 54 56 0A 20 20 20 20 20 20 |

Checksum(LG TV): Changeable by total EDID data.

| | ① | ② | ③ |
|-------|----|----|---|
| HDMI1 | 42 | 1B | X |
| HDMI2 | 42 | 0B | X |
| HDMI3 | 42 | FB | X |

Vendor Specific(HDMI)

| INPUT | MODEL NAME(HEX) |
|-------|-------------------------|
| HDMI1 | 67 03 0C 00 10 00 80 1E |
| HDMI2 | 67 03 0C 00 20 00 80 1E |
| HDMI3 | 67 03 0C 00 30 00 80 1E |

4.2. White Balance Adjustment


4.2.1. Overview

- W/B adj. Objective & How-it-works
 - (1) Objective: To reduce each Panel's W/B deviation
 - (2) How-it-works : When R/G/B gain in the OSD is at 192, it means the panel is at its Full Dynamic Range. In order to prevent saturation of Full Dynamic range and data, one of R/G/B is fixed at 192, and the other two is lowered to find the desired value.
 - (3) Adjustment condition : normal temperature
 - 1) Surrounding Temperature : 25 °C ± 5 °C
 - 2) Surrounding Humidity : 20 % ~ 80 %

4.2.2. Equipment

- (1) Color Analyzer: CA-210 (LED Module : CH 14)
 - (2) Adjustment Computer(During auto adj., RS-232C protocol is needed)
 - (3) Adjustment Remote control
 - (4) Video Signal Generator MSPG-925F 720p/204-Gray (Model: 217, Pattern: 49)
 - Only when internal pattern is not available
- Color Analyzer Matrix should be calibrated using CS-1000.

4.2.3. Equipment connection MAP



4.2.4. Adj. Command (Protocol)

<Command Format>

| | | | | | | | | | | | | | | | | |
|-------|----|---|----|---|-----|---|----|---|-----|---|----|---|-----|---|----|------|
| START | 6E | A | 50 | A | LEN | A | 03 | A | CMD | A | 00 | A | VAL | A | CS | STOP |
|-------|----|---|----|---|-----|---|----|---|-----|---|----|---|-----|---|----|------|

- LEN: Number of Data Byte to be sent
 - CMD: Command
 - VAL: FOS Data value
 - CS: Checksum of sent data
 - A: Acknowledge
- Ex) [Send: JA_00_DD] / [Ack: A_00_okDDX]

- RS-232C Command used during auto-adjustment.

| RS-232C COMMAND | | | Explanation |
|-----------------|----|--------|-------------------------------------------------------------|
| [CMD] | ID | [DATA] | |
| wb | 00 | 00 | Begin White Balance adjustment |
| wb | 00 | 10 | Gain adjustment(internal white pattern) |
| wb | 00 | 1f | Gain adjustment completed |
| wb | 00 | 20 | Offset adjustment(internal white pattern) |
| wb | 00 | 2f | Offset adjustment completed |
| wb | 00 | ff | End White Balance adjustment (internal pattern disappears) |

- Ex) wb 00 00 -> Begin white balance auto-adj.
 wb 00 10 -> Gain adj.
 ja 00 ff -> Adj. data
 jb 00 c0
 ...
 ...
 wb 00 1f → Gain adj. completed
 *(wb 00 20(Start), wb 00 2f(end)) → Off-set adj.
 wb 00 ff → End white balance auto-adj.

- Adj. Map

Applied Model : LD42B Chassis ALL MODELS

| | Adj. item | Command (lower caseASCII) | | Data Range (Hex.) | | Default (Decimal) |
|--------|-----------|---------------------------|------|-------------------|-----|-------------------|
| | | CMD1 | CMD2 | MIN | MAX | |
| Cool | R Gain | j | g | 00 | C0 | |
| | G Gain | j | h | 00 | C0 | |
| | B Gain | j | i | 00 | C0 | |
| | R Cut | | | | | |
| | G Cut | | | | | |
| | B Cut | | | | | |
| Medium | R Gain | j | a | 00 | C0 | |
| | G Gain | j | b | 00 | C0 | |
| | B Gain | j | c | 00 | C0 | |
| | R Cut | | | | | |
| | G Cut | | | | | |
| | B Cut | | | | | |
| Warm | R Gain | j | d | 00 | C0 | |
| | G Gain | j | e | 00 | C0 | |
| | B Gain | j | f | 00 | C0 | |
| | R Cut | | | | | |
| | G Cut | | | | | |
| | B Cut | | | | | |

4.2.5. Adj. method

- (1) Auto adj. method

- 1) Set TV in adj. mode using P-Only key.
 - 2) Zero calibrate probe then place it on the center of the Display.
 - 3) Connect Cable.(RS-232C to USB)
 - 4) Select mode in adj. Program and begin adj.
 - 5) When adj. is complete (OK Sign), check adj. status pre mode. (Cool, Medium, Warm)
 - 6) Remove probe and RS-232C cable to complete adj.
- W/B Adj. must begin as start command "wb 00 00" , and finish as end command "wb 00 ff", and Adj. offset if need.

- (2) Manual adjustment. method

- 1) Set TV in Adj. mode using P-Only key.
 - 2) Zero Calibrate the probe of Color Analyzer, then place it on the center of LCD module within 10 cm of the surface.
 - 3) Press ADJ key → EZ adjust using adj. R/C → 7. White-Balance then press the cursor to the right(key ►).
 (When right key(►) is pressed 204 Gray internal pattern will be displayed)
 - 4) One of R Gain / G Gain / B Gain should be fixed at 192, and the rest will be lowered to meet the desired value.
 - 5) Adjustment is performed in COOL, MEDIUM, WARM 3 modes of color temperature.
- If internal pattern is not available, use RF input. In EZ Adj. menu 7.White Balance, you can select one of 2 Test-pattern: ON, OFF. Default is inner(ON). By selecting OFF, you can adjust using RF signal in 204 Gray pattern.

- Adjustment condition and cautionary items

- 1) Lighting condition in surrounding area
 Surrounding lighting should be lower 10 lux. Try to isolate adj. area into dark surrounding.
- 2) Probe location
 : Color Analyzer(CA-210) probe should be within 10 cm and perpendicular of the module surface (80° ~ 100°)

4.2.6. Reference (White balance Adj. coordinate and color temperature)

- Luminance : 204 Gray
- Standard color coordinate and temperature using CS-1000 (over 26 inch)

| Mode | Coordinate | | Temp | Δuv |
|--------|------------|-------|---------|--------|
| | x | y | | |
| Cool | 0.271 | 0.270 | 13000 K | 0.0000 |
| Medium | 0.286 | 0.289 | 9300 K | 0.0000 |
| Warm | 0.313 | 0.329 | 6500 K | 0.0000 |

- Standard color coordinate and temperature using CA-210(CH 14)

| Mode | Coordinate | | Temp | Δuv |
|--------|---------------|---------------|---------|--------|
| | x | y | | |
| Cool | 0.271 ± 0.002 | 0.270 ± 0.002 | 13000 K | 0.0000 |
| Medium | 0.286 ± 0.002 | 0.289 ± 0.002 | 9300 K | 0.0000 |
| Warm | 0.313 ± 0.002 | 0.329 ± 0.002 | 6500K | 0.0000 |

4.2.7. LED White balance table

- EDGE LED module change color coordinate because of aging time.
- Apply under the color coordinate table, for compensated aging time.

Only march to December & Global

Model: (normal line)LGD (LB5xxx, LB6xxx, LB7xxx, LB8xxx)

| NC4.0 | Aging time (Min) | Cool | | Medium | | Warm | |
|-------|------------------|------|-----|--------|-----|------|-----|
| | | x | y | x | y | x | y |
| | | 271 | 270 | 286 | 289 | 313 | 329 |
| 1 | 0-2 | 282 | 289 | 297 | 308 | 324 | 348 |
| 2 | 3-5 | 281 | 287 | 296 | 306 | 323 | 346 |
| 3 | 6-9 | 279 | 284 | 294 | 303 | 321 | 333 |
| 4 | 10-19 | 277 | 280 | 292 | 299 | 319 | 339 |
| 5 | 20-35 | 275 | 277 | 290 | 296 | 317 | 336 |
| 6 | 36-49 | 274 | 274 | 289 | 293 | 316 | 333 |
| 7 | 50-79 | 273 | 272 | 288 | 291 | 315 | 331 |
| 8 | 80-119 | 272 | 271 | 287 | 290 | 314 | 330 |
| 9 | Over 120 | 271 | 270 | 286 | 289 | 313 | 329 |

Only January to Febuary & Global

Model: (normal line)LGD (LB5xxx, LB6xxx, LB7xxx, LB8xxx)

| NC4.0 | Aging time (Min) | Cool | | Medium | | Warm | |
|-------|------------------|------|-----|--------|-----|------|-----|
| | | x | y | x | y | x | y |
| | | 271 | 270 | 286 | 289 | 313 | 329 |
| 1 | 0-5 | 286 | 295 | 301 | 314 | 328 | 354 |
| 2 | 6-10 | 284 | 290 | 299 | 309 | 326 | 349 |
| 3 | 11-20 | 282 | 287 | 297 | 306 | 324 | 346 |
| 4 | 21-30 | 279 | 283 | 294 | 302 | 321 | 342 |
| 5 | 31-40 | 276 | 278 | 291 | 297 | 318 | 337 |
| 6 | 41-50 | 274 | 275 | 289 | 294 | 316 | 334 |
| 7 | 51-80 | 273 | 272 | 288 | 291 | 315 | 331 |
| 8 | 81-119 | 272 | 271 | 287 | 290 | 314 | 330 |
| 9 | Over 120 | 271 | 270 | 286 | 289 | 313 | 329 |

AUO, INX, Sharp, CSOT, BOE (Cool : 13000 K)

| NC4.0 | Cool | | Medium | | Warm | |
|--------|------|-----|--------|-----|------|-----|
| | x | y | x | y | x | y |
| spec | 271 | 270 | 286 | 289 | 313 | 329 |
| target | 278 | 280 | 293 | 299 | 320 | 339 |

4.3. Local Dimming Function Check

(1) Normal Edge LED Model


Step 1) Turn on TV.

Step 2) Press "TILT" key on the Adj. Remote control.

Step 3) At the Local Dimming mode, module Edge Backlight moving right to left Back light of IOP module moving.

Step 4) Confirm the Local Dimming mode.

Step 5) Press "exit" key.



Local Dimming Demo.
(Edge LED Model)


(2) Only 50inch AUO Local dimming Model(50LA66)

- Test method


Insert the USB memory included video file below inspection pattern in Poweronly mode.

Play repeat first, second pattern once per second

If the circle of each side flicker, Local dimming function is OK



< First Pattern >



< Second Pattern >

(3) Only LA71 Series LGD Local Dimming Model (47/55LA71, 16 block)


Step 1) Turn on TV

Step 2) Press "TILT" key on the Adj. R/C.

Step 3) At the Local Dimming mode, module Edge Backlight moving left to right, bottom to Up, Back light of ALEF module moving. (No1->2->3->....->14->15->16)

Step 4) Confirm the Local Dimming mode



Step 5) Press "exit" Key



Direction

4.4. Magic Motion Remote control test

- Results are automatically marked in Instart OSD after through the AP/Magic Remocon Equipment on the line



4.5. 3D function test(Except Non-3D product)

(Pattern Generator MSHG-600, MSPG-6100[Support HDMI1.4])

* HDMI mode NO. 872 , pattern No.83

(1) Please input 3D test pattern like below.



(2) When 3D OSD appear automatically, then select OK key.



(3) Don't wear a 3D Glasses, check the picture like below.




4.6. Wi-Fi Test

Step 1) Turn on TV


Step 2) Select Wi-Fi Connection option in Network Menu.




Step 3) Click Off Button to On in Wi-Fi Connection.



Step 4) The system finds any AP like blow PIC.



Step 5) Select the AP you want to connect.



4.7. LNB voltage and 22KHz tone check

(only for DVB-S/S2 model)

▪ Test method

- (1) Set TV in Adj. mode using POWER ON.
- (2) Connect cable between satellite ANT and test JIG.
- (3) Press Yellow key(ETC+SWAP) in Adj Remote control to make LNB on.
- (4) Check LED light 'ON' at 18 V menu.
- (5) Check LED light 'ON' at 22 KHz tone menu.
- (6) Press Blue key(ETC+PIP INPUT) in Adj Remote control to make LNB off.
- (7) Check LED light 'OFF' at 18 V menu.
- (8) Check LED light 'OFF' at 22 KHz tone menu.

▪ Test result

- (1) After press LNB On key, '18 V LED' and '22 KHz tone LED' should be ON.
- (2) After press LNB OFF key, '18 V LED' and '22 KHz tone LED' should be OFF.

4.8. Option selection per country

4.8.1. Overview

- Option selection is only done for models in Non-EU

4.8.2. Method

- (1) Press ADJ key on the Adj. R/C, then select Country Group Meun.
- (2) Select Country Group Code 04 or Country Group EU.

5. Tool Option selection

- Method : Press "ADJ" key on the Adjustment remote control, then select Tool option.

6. Ship-out mode check(In-stop)

- After final inspection, press "IN-STOP" key of the Adjustment remote control and check that the unit goes to Stand-by mode.

7. GND and Internal Pressure check

7.1. Method

- (1) GND & Internal Pressure auto-check preparation
 - Check that Power cord is fully inserted to the SET.
(If loose, re-insert)
- (2) Perform GND & Internal Pressure auto-check
 - Unit fully inserted Power cord, Antenna cable and A/V arrive to the auto-check process.
 - Connect D-terminal to AV JACK TESTER
 - Auto CONTROLLER(GWS103-4) ON
 - Perform GND TEST
 - If NG, Buzzer will sound to inform the operator.
 - If OK, changeover to I/P check automatically.
(Remove CORD, A/V form AV JACK BOX.)
 - Perform I/P test
 - If NG, Buzzer will sound to inform the operator.
 - If OK, Good lamp will lit up and the stopper will allow the pallet to move on to next process.

7.2. Checkpoint

- TEST voltage
 - (1) DQA Test
 - GND: 1.5 KV / min at 100 mA
 - SIGNAL: 3 KV / min at 100 mA
 - (2) Mass Production Line Test
 - GND: AC 1.5 KV / sec, Cut off current not exceed 100 mA
- TEST time: DQA 1 min, Mass Production Line 1 sec
- TEST POINT
 - GND TEST = POWER CORD GND & SIGNAL CABLE METAL GND
 - Internal Pressure TEST = POWER CORD GND & LIVE & NEUTRAL
- LEAKAGE CURRENT: At 0.5 mArms

8. Audio


Measurement condition:

| No. | Item | Min | Typ | Max | Unit | Remark |
|-----|-------------------------------------------------------------|-----|------|------|------|--------------------------------------|
| 1. | Audio practical max Output, L/R (Distortion=10% max Output) | 9 | 10 | 12 | W | EQ Off AVL Off Clear Voice Off |
| | | | 8.10 | 10.8 | Vrms | |
| 2. | Speaker (8Ω Impedance) | 9 | 10 | 12 | W | |


- (1) RF input: Mono, 1 KHz sine wave signal, 100 % Modulation
- (2) CVBS, Component: 1 KHz sine wave signal 0.5 Vrms
- (3) RGB PC: 1 KHz sine wave signal 0.7 Vrms

9. USB S/W Download(Service only)

- (1) Put the USB Stick to the USB socket.
- (2) Go to General menu then enter to About This TV.



- (3) Enter the USB EXPERT MODE.




- (4) Updating is starting.
- (5) Updating completed, the TV will restart automatically
- (6) If your TV is turned on, check your updated version and Tool option. (explain the Tool option, next stage)
 - * If downloading version is more high than your TV have, TV can lost all channel data. In this case, you have to channel recover. if all channel data is cleared, you didn't have a DTV/ATV test on production line.

* After downloading, have to adjust Tool Option again.

- (1) Push "IN-START" key in service remote control.
- (2) Select "Tool Option 1" and push "OK" key.
- (3) Punch in the number. (Each model has their number)


BLOCK DIAGRAM



EXPLODED VIEW


IMPORTANT SAFETY NOTICE

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These parts are identified by Δ in the Schematic Diagram and EXPLODED VIEW. It is essential that these special safety parts should be replaced with the same components as recommended in this manual to prevent X-RADIATION, Shock, Fire, or other Hazards. Do not modify the original design without permission of manufacturer.




System Configuration





Clock for M14-A0



NVRAM




PLL SET[1:0] : internal pull up
 00 : CPU(1200Mhz), M0 / M1 DDR(792.792 Mhz)
 01 : CPU(1056Mhz), M0 / M1 DDR(792.792 Mhz)
 10 : CPU(1056Mhz), M0 / M1 DDR(792.792 Mhz)
 11 : CPU(960Mhz), M0 / M1 DDR(792.792 Mhz)




I2C


I2C_1 : AMP
 I2C_2 : T-CON,L/DIMING
 I2C_3 : MICOM
 I2C_4 : S/Demod,T2/Demod, LNB
 I2C_5 : NVRAM
 I2C_6 : TUNER_MOPL(T/C,ATV)




LOCAL DIMMING I2C CONTROL




IC101 LG1311



Jtag-0 I/F



Jtag-1 I/F




THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.


SECRET
LGElectronics



| | | | |
|-------|--------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | M14 Symbol A | SHEET | 1 / 31 |




| BIT [6/7] | EU/CIS | AJJA | TAIWAN/COL | CHINA/HONG | KOREA | NORTH AMERICA | BRAZIL | JAPAN |
|-----------|-----------------|--------------|------------|------------|----------|---------------|----------|---------|
| 0 / 0 | T/C | T/C | T/C | Default | ATSC PIP | ATSC PIP | ISDB PIP | Default |
| 0 / 1 | T2/C/82/ATV_EXT | T2/C/ATV_EXT | T2/C PIP | | ATV_SDC | ATV_SDC | ISDB | |
| 1 / 0 | T2/C | T2/C/ATV_SDC | T2/C | | ATV_EXT | ATV_EXT | | |
| 1 / 1 | T2/C/82/ATV_SDC | T2/C/82 | | | | | | |



| BIT [0/1] | DVB | ATSC | JP |
|-----------|----------------|-----------|-------|
| 0 / 0 | TAIWAN/COLON | N/AMERICA | |
| 0 / 1 | CHINA/HONGKONG | KOREA | JAPAN |
| 1 / 0 | EU/CIS | S/AMERICA | |
| 1 / 1 | ASIA/AFRICA | | |

| BIT[2/3/4/5] | TYPE | FHD | FRC | PANEL TYPE |
|---------------|------|-----|-------|---------------------|
| 0 / 0 / 0 / 0 | EPI | FHD | 120Hz | V14 (8 lane) |
| 0 / 0 / 0 / 1 | EPI | FHD | 120Hz | V14_32inch (6 lane) |
| 0 / 0 / 1 / 1 | EPI | FHD | 120Hz | V13 (6 lane) |
| 0 / 0 / 1 / 1 | EPI | FHD | 120Hz | V12 (6 lane) |
| 0 / 1 / 0 / 0 | EPI | FHD | 60Hz | V14_32 inch (6lane) |
| 0 / 1 / 0 / 1 | LVDS | FHD | 120Hz | |
| 0 / 1 / 1 / 0 | LVDS | FHD | 60Hz | |
| 0 / 1 / 1 / 1 | LVDS | HD | 60Hz | |
| 1 / 0 / 0 / 0 | LVDS | FHD | 60Hz | CP BOX |
| 1 / 0 / 0 / 1 | LVDS | HD | 60Hz | SMALL SMART |
| 1 / 0 / 1 / 0 | Vby1 | FHD | 120Hz | OLED |
| 1 / 0 / 1 / 1 | LVDS | FHD | 120Hz | OLED |
| 1 / 1 / 0 / 0 | | | | |
| 1 / 1 / 0 / 1 | | | | |
| 1 / 1 / 1 / 0 | | | | |
| 1 / 1 / 1 / 1 | | | | |

| MODEL_OPTION | LOW | HIGH |
|--------------|--------|-------------|
| MODEL_OPT_8 | DDR3 | NON_DDP |
| MODEL_OPT_9 | DDR3 | 2GB |
| MODEL_OPT_10 | FOR UD | NON_DDR3 3G |
| MODEL_OPT_11 | | DDR3 3G |
| MODEL_OPT_12 | | |



THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics







| | | | |
|-------|--------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | M14 Symbol B | SHEET | 2 / 31 |



Place JACK Side

Place SOC Side


AV1_CVBS/COMP1_Y Circuit was moved to 34Page





AUDIO IN



DDR3 VENDOR OPTION



AUDIO OUT




- DDC_SCL_3 TP321
- DDC_SDA_3 TP322
- HDMI_HPD_3 TP323
- 5V_HDMI_3_Soc TP324
- D0+_HDMI3 TP325
- D0-HDMI3 TP326
- D1+_HDMI3 TP327
- D1-HDMI3 TP328
- D2+_HDMI3 TP329
- D2-HDMI3 TP330
- CK+_HDMI3 TP331
- CK-HDMI3 TP332

THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IT IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|--------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | M14 Symbol C | SHEET | 3 / 31 |




THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|-------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | M14_DDR3-M0 | SHEET | 4 / 31 |












THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics

LG ELECTRONICS

| | | | |
|-------|-------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | M14 DDR3-M1 | SHEET | 5 / 31 |

IC101
LG1311




THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.04 |
| BLOCK | VCC & GND | SHEET | 6 / 31 |















THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.03.22 |
| BLOCK | PCMCIA | SHEET | 7 / 31 |






THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics





| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.03.22 |
| BLOCK | POWER | SHEET | 8 / 31 |



MICOM MODEL OPTION

| | 0 | 1 | |
|-------------|--------------------|--------------------|-------------------------|
| MODEL_OPT_0 | NON LOGO | LOGO | For LOGO LIGHT |
| MODEL_OPT_1 | LCD | OLED/UND | Need to Assign ADC port |
| MODEL_OPT_2 | NC4_Local KEY_SKEY | NC5_Local KEY_SKEY | Ready for sample set |
| MODEL_OPT_3 | M14 | H13/H14 | |
| MODEL_OPT_4 | NON_GED | GED | |










THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.03.22 |
| BLOCK | MICOM | SHEET | 9 / 31 |




THE Δ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE Δ SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics




| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.03.22 |
| BLOCK | HDMI | SHEET | 32 |


SPDIF OUT




HP OUT




DDTS TEST ONLY



UART for Debug





AV/COMPONENT REAR



THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

| | |
|---------------|----------------|
| SECRET | LG ELECTRONICS |
| LGElectronics | |

| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | AV JACK | SHEET | 11 / 31 |







THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.03.22 |
| BLOCK | IR / KEY | SHEET | 12 / 31 |




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


| | |
|---------------|-------------------------------------------------------------------------------------------------------------|
| SECRET |  LG ELECTRONICS |
| LGElectronics | |



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | USB 2 & 3 | SHEET | 1 / |

OCF USB1



USB1 (2.0)
MAX 1.5A






THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

| | |
|---------------|------------------------------------------------------------------------------------------------------|
| SECRET |  LG ELECTRONICS |
| LGElectronics | |

| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | USB 1(DVR) | SHEET | 1 / |

Full Scart




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics




| | | | |
|-------|--|-------|---|
| MODEL | | DATE | |
| BLOCK | | SHEET | / |

Ethernet Block





THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|--|-------|---|
| MODEL | | DATE | |
| BLOCK | | SHEET | / |

Ethernet Block



WOL_SW Multi add, 131120
USE this after 131201


THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics






| | | | |
|-------|--|------------|--|
| MODEL | | DATE | |
| BLOCK | | SHEET | |
| | | 2012-09-12 | |

BSD-NC4_H052-HD




[SCART AUDIO MUTE]





THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


| | |
|---------------|------------------------------------------------------------------------------------------------------|
| SECRET |  LG ELECTRONICS |
| LGElectronics | |

| | | | |
|-------|-----------|-------|------------|
| MODEL | MID_MAIN | DATE | 2013.03.19 |
| BLOCK | SCART AMP | SHEET | 3 / 25 |




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics




| | | | |
|-------|---------------|-------|------------|
| MODEL | HEADPHONE AMP | DATE | 2011.09.29 |
| BLOCK | | SHEET | 61 / |




THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.



SECRET
LGElectronics



| | | | |
|-------|--|-------|---|
| MODEL | | DATE | |
| BLOCK | | SHEET | / |

B-CAS (SMART CARD) INTERFACE




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

| | |
|---------------|------------------------------------------------------------------------------------------------------|
| SECRET |  LG ELECTRONICS |
| LGElectronics | |

| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | B-CAS I/F | SHEET | / |

○ /TU_RESET2_TU ○ /TU_RESET2
 ● FE_DEMOD1_TS_ERROR



1. should be guarded by ground
2. No via on both of them
3. Signal Width >= 12mils
Signal to Signal Width = 12mils
Ground Width >= 24mils



Global F/E Option Name
 1. TU
 2. Tuner Name = TDJ'H',TDJ'M'...
 3. Country Name = KR,US,BR,EU ...

Example of Option name
 TU_ALL_IntDemod = All Tuner type for Internal demod
 TU_M/W = apply TDSM&TDSW Type Tuner

14' Tuner Type for Global
 TDJ'H'-G101D : Half NIM for EU,AJJA
 TDJ'H'-H101F : Half NIM for US, KR
 TDJ'K'-T101F : Half NIM for TW
 TDJ'M'-C301D,F : FULL NIM for China
 TDJ'M'-B101F : Brazil NIM with Isolater Type
 TDJ'M'-K101F : colombia NIM
 TDJ'M'-G101D,G105D,G151D : EU Combo&Full NIM
 TDJ'M'-H101F,H151F : Korea PIP tuner
 TDJ'W'-A151D : AJJA T2 PIP




THE ⚠ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE ⚠ SYMBOL MARK OF THE SCHEMATIC.

SECRET
 LGElectronics



| | | | |
|-------|-------|-------|------------|
| MODEL | TUNER | DATE | 2012.07.10 |
| BLOCK | | SHEET | 65 |



THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics




| | | | |
|-------|-----------|-------|------------|
| MODEL | TU_SYMBOL | DATE | 2012.09.14 |
| BLOCK | | SHEET | / |

DVB-S2 LNB Part Allegro

(Option:LNB)


3A

Input trace widths should be sized to conduct at least 3A
Output trace widths should be sized to conduct at least 2A



THE ⚠ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION, FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE ⚠ SYMBOL MARK OF THE SCHEMATIC.



SECRET
LGElectronics



| | | | |
|-------|-----|-------|------------|
| MODEL | LNB | DATE | 2012.03.08 |
| BLOCK | | SHEET | 69 / |

[51Pin LVDS OUTPUT Connector]

[41Pin LVDS OUTPUT Connector]




THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-----------------|----------------|-------|------------|
| BSD-NC4_H072-HD | | | |
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | LVDS INTERFACE | SHEET | / |




THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IT IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



BSD-NC4_H074-HD

| | | | |
|-------|---------------|-------|------------|
| MODEL | LOCAL DIMMING | DATE | 2012.09.14 |
| BLOCK | | SHEET | / |








V14-LGD PANEL

EPI 8-Lane (LEFT)

EPI 8-Lane (RIGHT)



P7702
FL11S050HA1

P7703
FL11S050HA1



< VCOM OPTION TABLE >

| V14 42-55INCH | | | | V14 32INCH | | | | | | | |
|--------------------|----------------|--------------------|----------------|--------------------|----------------|--------------------|----------------|--------|-------|--------|--------|
| EXT.OP AMP NOT USE | EXT.OP AMP USE | EXT.OP AMP NOT USE | EXT.OP AMP USE | EXT.OP AMP NOT USE | EXT.OP AMP USE | EXT.OP AMP NOT USE | EXT.OP AMP USE | | | | |
| IC7702 | NC | R7716 | 0 ohm | IC7702 | USE | R7710 | 0 ohm | IC7702 | NC | IC7702 | USE |
| C7760 | NC | R7766 | 0 ohm | C7760 | USE | R7716 | NC | C7760 | NC | C7760 | USE |
| L7706 | NC | R7767 | NC | L7706 | USE | R7766 | 0 ohm | L7706 | NC | L7706 | USE |
| R7770 | 0 ohm | R7719 | 0 ohm | R7770 | 1kOhm | R7767 | NC | R7770 | NC | R7770 | 1kOhm |
| R7772 | 0 ohm | R7721 | 0 ohm | R7772 | 0 ohm | R7719 | 0 ohm | R7772 | NC | R7772 | 0 ohm |
| R7708 | 0 ohm | R7771 | NC | R7708 | 30Kohm | R7721 | 0 ohm | R7708 | NC | R7708 | 30Kohm |
| R7705 | 0 ohm | R7708 | 0 ohm | R7705 | 0 ohm | R7708 | 0 ohm | R7705 | 0 ohm | R7705 | 0 ohm |
| R7710 | NC | R7712 | NC | R7710 | 0 ohm | R7712 | 0 ohm | R7710 | 0 ohm | R7710 | 0 ohm |
| | | R7714 | NC | | | R7714 | 0 ohm | | | | |






THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IT IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics



| | | | |
|-------|------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.03 |
| BLOCK | T-Con | SHEET | 77 |




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

| | |
|---------------|------------------------------------------------------------------------------------------------------|
| SECRET |  LG ELECTRONICS |
| LGElectronics | |

| | | | |
|-------|------------------|-------|------------|
| MODEL | MID_LG1311 | DATE | 2013.04.02 |
| BLOCK | IR Blaster/Boost | SHEET | 110 / |

RS-232C Control INTERFACE



THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET
LGElectronics






| | | | |
|-------|--|-------|---|
| MODEL | | DATE | |
| BLOCK | | SHEET | / |



PLACE AT JACK SIDE

SCART SIGNAL (Use only EU/CIS Model)

Place JACK Side

Place SOC Side



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION, FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURERS SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

| | |
|--------------------------------|-------------------------------------------------------------------------------------------------------------|
| SECRET LGElectronics |  LG ELECTRONICS |
|--------------------------------|-------------------------------------------------------------------------------------------------------------|

| | | | |
|-------|--|-------|---|
| MODEL | | DATE | |
| BLOCK | | SHEET | / |



M14 Trouble Shooting Guide


Contents of LCD TV Standard Repair Process

| No. | Error symptom (High category) | Error symptom (Mid category) | Page | Remarks |
|-----|-------------------------------|----------------------------------------------------------------------------------|------|---------|
| 1 | A. Video error | No video/Normal audio | 2 | |
| 2 | | No video/No audio | 3 | |
| 3 | | Picture Broken / Freezing | 4 | |
| 4 | | Color error | 5 | |
| 5 | | Vertical/Horizontal bar, residual image, light spot, external device color error | 6 | |
| 6 | B. Power error | No power | 7 | |
| 7 | | Off when on, off while viewing, power auto on/off | 8 | |
| 8 | C. Audio error | No audio/Normal video | 9 | |
| 9 | | Wrecked audio/discontinuation/noise | 10 | |
| 10 | D. Function error | No response in remote controller, key error, recording error, memory error | 11 | |
| 11 | | External device recognition error | 12 | |
| 12 | E. Noise | Circuit noise, mechanical noise | 13 | |
| 13 | F. Exterior error | Exterior defect | 14 | |

First of all, Check whether there is SVC Bulletin in GCSC System for these model.

| | | | | | |
|--------|---------------|------------------------|------------------|------------|------|
| LCD TV | Error symptom | A. Video error | Established date | 2014.01.20 | |
| | | No video/ Normal audio | Revised date | | 1/13 |


**First of all, Check whether all of cables between board is inserted properly or not.
(Main B/D↔ Power B/D, EPI Cable, Speaker Cable, IR B/D Cable,,,))**



※Precaution A7 & A3



| | | | | | |
|-------------------------|---------------|--------------------|--|------------------|------------|
| Standard Repair Process | | | | | |
| LCD TV | Error symptom | A. Video error | | Established date | 2014.01.20 |
| | | No video/ No audio | | Revised date | 2/13 |




| | | | | | |
|--------|---------------|---------------------------|------------------|------------|------|
| LCD TV | Error symptom | A. Picture Problem | Established date | 2014.01.20 | |
| | | Picture broken/ Freezing | Revised date | | 3/13 |


A6

Check RF Signal level

- . By using Digital signal level meter
- . By using Diagnostics menu on OSD
(Setting → Set up → Manual Tuning → Check the Signal)
- Signal strength (Normal : over 50%)
- Signal Quality (Normal: over 50%)




| Standard Repair Process | | | | | |
|-------------------------|---------------|----------------|------------------|------------|------|
| LCD TV | Error symptom | A. Video error | Established date | 2014.01.20 | |
| | | Color error | Revised date | | 4/13 |




| | | | | | |
|--------|---------------|------------------------------------------------------------------------------------|------------------|------------|------|
| LCD TV | Error symptom | A. Video error | Established date | 2014.01.20 | |
| | | Vertical / Horizontal bar, residual image, light spot, external device color error | Revised date | | 5/13 |


Vertical/Horizontal bar, residual image, light spot




External device screen error-Color error



| | | | | | |
|-------------------------|---------------|----------------|--|------------------|------------|
| Standard Repair Process | | | | | |
| LCD TV | Error symptom | B. Power error | | Established date | 2014.01.20 |
| | | No power | | Revised date | 6/13 |




| | | | | | |
|--------|---------------|---------------------------------------------------|------------------|------------|------|
| LCD TV | Error symptom | B. Power error | Established date | 2014.01.20 | |
| | | Off when on, off while viewing, power auto on/off | Revised date | | 7/13 |



* Please refer to the all cases which can be displayed on power off mode.


| Status | Power off List | Explanation |
|----------|------------------------------------------------|------------------------------------------------------------------------------|
| Normal | "POWEROFF_REMOTEKEY" | Power off by REMOTE CONTROL |
| | "POWEROFF_OFFTIMER" | Power off by OFF TIMER |
| | "POWEROFF_SLEEPTIMER" | Power off by SLEEP TIMER |
| | "POWEROFF_INSTOP" | Power off by INSTOP KEY |
| | "POWEROFF_AUTOOFF" | Power off by AUTO OFF |
| | "POWEROFF_ONTIMER" | Power off by ON TIMER |
| | "POWEROFF_RS232C" | Power off by RS232C |
| | "POWEROFF_RESREC" | Power off by Reserved Record |
| | "POWEROFF_RECEND" | Power off by End of Recording |
| | "POWEROFF_SWDOWN" | Power off by S/W Download |
| Abnormal | "POWEROFF_UNKNOWN" | Power off by unknown status except listed case |
| | "POWEROFF_ABNORMAL1" "POWEROFF_CPUABNORMAL" | Power off by abnormal status except CPU trouble Power off by CPU Abnormal |

| | | | | | |
|--------|---------------|------------------------|------------------|------------|------|
| LCD TV | Error symptom | C. Audio error | Established date | 2014.01.20 | |
| | | No audio/ Normal video | Revised date | | 8/13 |




| | | | | | |
|--------|---------------|--------------------------------------|------------------|------------|------|
| LCD TV | Error symptom | C. Audio error | Established date | 2014.01.20 | |
| | | Wrecked audio/ discontinuation/noise | Revised date | | 9/13 |


→ abnormal audio/discontinuation/noise is same after “Check input signal” compared to No audio




| | | | | | |
|--------|---------------|----------------------------------------|------------------|------------|-------|
| LCD TV | Error symptom | D. General Function Problem | Established date | 2014.01.20 | |
| | | Remote control & Local switch checking | Revised date | | 10/13 |




| | | | | | |
|--------|---------------|-----------------------------------|------------------|------------|-------|
| LCD TV | Error symptom | D. Function error | Established date | 2014.01.20 | |
| | | External device recognition error | Revised date | | 11/13 |



| | | | | | |
|---------------|----------------------|---------------------------------|-------------------------|-------------------|--------------|
| LCD TV | Error symptom | E. Noise | Established date | 2014.01.20 | |
| | | Circuit noise, mechanical noise | Revised date | | 12/13 |



| | | | | | |
|---------------|---------------|---------------------------|------------------|------------|-------|
| LCD TV | Error symptom | F. Exterior defect | Established date | 2014.01.20 | |
| | | Exterior defect | Revised date | | 13/13 |



Contents of LCD TV Standard Repair Process Detail Technical Manual

| No. | Error symptom | Content | Page | Remarks |
|-----|---------------------------------------------------------------------------|------------------------------------------------|------------|---------|
| 1 | A. Video error_ No video/Normal audio | Check LCD back light with naked eye | A1 | |
| 2 | | LED driver B+ 24V measuring method | A2 | |
| 3 | | Check White Balance value | A3 | |
| 4 | | Power Board voltage measuring method | A4 | |
| 6 | A. Video error_ No video/Video lag/stop | TUNER input signal strength checking method | A6 | |
| 7 | | LCD-TV Version checking method | A7 | |
| 9 | A. Video error_Color error | LCD TV connection diagram | A8 | |
| 11 | | Check Link Cable (LVDS) reconnection condition | A10 | |
| 12 | | Adjustment Test pattern – ADJ Key | A12 | |
| 13 | A. Video error_Vertical/Horizontal bar, residual image, light spot | LCD TV connection diagram | A8 | |
| 14 | | Check Link Cable (LVDS) reconnection condition | A10 A11 | |
| 15 | | Adjustment Test pattern – ADJ Key | A12 | |
| 16 | <Appendix> Defected Type caused by Main/ Inverter/ Module | Exchange Main Board or EPI Cable | A- 1/5 | |
| 17 | | Exchange Main Board or EPI Cable | A- 2/5 | |
| 18 | | Exchange LED driver Board (PSU) | A- 3/5 | |
| 19 | | Exchange Module itself (1) | A- 4/5 | |
| 20 | | Exchange Module itself (2) | A- 5/5 | |


Contents of LCD TV Standard Repair Process Detail Technical Manual

Continued from previous page

| No. | Error symptom | Content | Page | Remarks |
|-----|----------------------------------------------------------------|------------------------------------------------------------|------|---------|
| 21 | B. Power error_No power | Check front display LED | A17 | |
| 22 | | Check power input Voltage & ST-BY 5V | A18 | |
| 23 | | Checking method when power is ON | A19 | |
| 24 | B. Power error_Off when on, off while viewing | POWER OFF MODE checking method | A22 | |
| 25 | C. Audio error_No audio/Normal video | Checking method in menu when there is no audio | A24 | |
| 26 | | Voltage and speaker checking method when there is no audio | A25 | |
| 27 | C. Audio error_Wrecked audio/discontinuation | Voltage and speaker checking method in case of audio error | A25 | |
| 28 | D. Function error_ No response in remote controller, key error | Remote controller operation checking method | A27 | |
| 29 | Display has error especially color | V-Com checking and adjust method | A28 | |
| | | | | |
| | | | | |
| | | | | |

Standard Repair Process Detail Technical Manual


| | | | | | |
|--------|---------------|--------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_No video/Normal audio | Established date | 2014. 01 .20 | |
| | Content | Check LCD back light with naked eye | Revised date | | A1 |



After turning on the power and disassembling the case, check with the naked eye, whether you can see light from module holes.

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_No video/Normal audio | Established date | 2014. 01 .20 | |
| | Content | LED driver B+ 24V measuring method | Revised date | | A2 |






Check the DC 24V

| 24 Pin | |
|-----------|-----|
| 9, 10, 16 | 24V |

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_No video/Normal audio | Established date | 2014. 01 .20 | |
| | Content | Check White Balance value | Revised date | | A3 |

<ALL MODELS>



Entry method

1. Press the ADJ button on the remote controller for adjustment.
2. Enter into White Balance of item 10.
3. After recording the R, G, B (GAIN, Cut) value of Color Temp (Cool/Medium/Warm), re-enter the value after replacing the MAIN BOARD.

A3

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_No video/ Audio | Established date | 2014. 01 .20 | |
| | Content | Power Board voltage measuring method | Revised date | | A4 |

Check the 12V, 3.5V.



| 24 Pin (Power Board ↔ Main Board) | | | |
|-----------------------------------|-------------|----|-------------|
| SMAW200-H24S5 | | | |
| 1 | Power on | 2 | Inverter On |
| 3 | 3.5V | 4 | PWM#1 |
| 5 | 3.5V | 6 | 3.5V |
| 7 | GND | 8 | PWM#2 |
| 9 | 24V | 10 | 24V |
| 11 | GND | 12 | GND |
| 13 | 12V | 14 | 12V |
| 15 | 12V | 16 | 24V |
| 17 | GND | 18 | GND |
| 19 | GND | 20 | GND |
| 21 | GND | 22 | L/DIM0_VS |
| 23 | L/DIM0_MOSI | 24 | L/DIM0_SCLK |

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|---------------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_Video error, video lag/stop | Established date | 2014. 01 .20 | |
| | Content | TUNER input signal strength checking method | Revised date | | A6 |

<ALL MODELS>



Settings → Quick → Programmes
→ Programme Tuning



When the signal is strong, use the attenuator (-10dB, -15dB, -20dB etc.)




Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error_Video error, video lag/stop | Established date | 2014. 01 .20 | |
| | Content | LCD-TV Version checking method | Revised date | | A7 |

<ALL MODELS>

1. Checking method for remote controller for adjustment

Version




Press the IN-START with the remote controller for adjustment

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|---------------------------------------------------------------------|------------------|--------------|----|
| LCD TV | Error symptom | A. Video error _Vertical/Horizontal bar, residual image, light spot | Established date | 2014. 01 .20 | |
| | Content | LCD TV connection diagram | Revised date | | A8 |

[LD42B models]




As the part connecting to the external input, check the screen condition by signal

[LD42A models]



Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|-----------------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | A. Video error_Color error | Established date | 2011. 12 .14 | |
| | Content | Check Link Cable (EPI) reconnection condition | Revised date | | A10 |




Check the contact condition of the Link Cable, especially dust or mis insertion.

A10

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|-----------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | A. Video error_Color error | Established date | 2014. 01 .20 | |
| | Content | Adjustment Test pattern - ADJ Key | Revised date | | A12 |




You can view 6 types of patterns using the ADJ Key

Checking item : 1. Defective pixel 2. Residual image 3. MODULE error (ADD-BAR,SCAN BAR..) 4.Video error (Classification of MODULE or Main-B/D!)


Appendix : Exchange EPI Cable or Main B/D (1)



Solder defect, CNT Broken




Solder defect, CNT Broken



Solder defect, CNT Broken




Solder defect, CNT Broken



Solder defect, CNT Broken



Abnormal Power Section



Solder defect, Short/Crack



Abnormal Power Section



Solder defect, Short/Crack

Appendix : Exchange EPI Cable or Main B/D (2)



Abnormal Power Section



Abnormal Power Section



Solder defect, Short/Crack




Solder defect, Short/Crack



Fuse Open, Abnormal power section



Abnormal Display



GRADATION



Noise



GRADATION


Appendix : Exchange Power Board



No Light



Dim Light



Dim Light



Dim Light



No picture/Sound Ok

Appendix : Exchange the Module (1)




Panel Mura, Light leakage



Panel Mura, Light leakage



Press damage



Crosstalk



Press damage




Crosstalk



Press damage

Un-repairable Cases
In this case please exchange the module.

Appendix : Exchange the Module (2)



Vertical Block
Source TAB IC Defect



Vertical Line
Source TAB IC Defect



Vertical Block
Source TAB IC Defect



Horizontal Block
Gate TAB IC Defect



Horizontal Block
Gate TAB IC Defect



Horizontal line
Gate TAB IC Defect



Horizontal Block
Gate TAB IC Defect

Un-repairable Cases

In this case please exchange the module.

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | B. Power error _No power | Established date | 2014. 01 .20 | |
| | Content | Check front display LED | Revised date | | A17 |



Front LED control :
Menu → General →
Standby Light
→ ON/ Off




ST-BY condition: Red
Power ON condition: Turn Off

A17

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|----------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | B. Power error _No power | Established date | 2014. 01 .20 | |
| | Content | Checking method when power is ON | Revised date | | A19 |

Check "power on" pin is high




| 24 Pin (Power Board ↔ Main Board) | | | |
|-----------------------------------|-------------|----|-------------|
| SMAW200-H24S5 | | | |
| 1 | Power on | 2 | Inverter On |
| 3 | 3.5V | 4 | PWM#1 |
| 5 | 3.5V | 6 | 3.5V |
| 7 | GND | 8 | PWM#2 |
| 9 | 24V | 10 | 24V |
| 11 | GND | 12 | GND |
| 13 | 12V | 14 | 12V |
| 15 | 12V | 16 | 24V |
| 17 | GND | 18 | GND |
| 19 | GND | 20 | GND |
| 21 | GND | 22 | L/DIM0_VS |
| 23 | L/DIM0_MOSI | 24 | L/DIM0_SCLK |

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|--------------------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | B. Power error _Off when on, off whiling viewing | Established date | 2014. 01 .20 | |
| | Content | POWER OFF MODE checking method | Revised date | | A22 |

<ALL MODELS>




Entry method

1. Press the IN-START button of the remote controller for adjustment
2. Check the entry into adjustment item 3

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|------------------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | C. Audio error_No audio/Normal video | Established date | 2014. 01 .20 | |
| | Content | Checking method in menu when there is no audio | Revised date | | A24 |

<ALL MODELS>



Checking method

1. Press the Setting button on the remote controller
2. Select the Sound function of the Menu
3. Select the Sound Out
4. Select TV Speaker

A24

Standard Repair Process Detail Technical Manual


| | | | | | |
|--------|---------------|------------------------------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | C. Audio error_No audio/Normal video | Established date | 2014. 01 .20 | |
| | Content | Voltage and speaker checking method when there is no audio | Revised date | | A25 |

24 Pin (Power Board ↔ Main Board)


SMAW200-H24S5

| | | | |
|----|-------------|----|-------------|
| 1 | Power on | 2 | Inverter On |
| 3 | 3.5V | 4 | PWM#1 |
| 5 | 3.5V | 6 | 3.5V |
| 7 | GND | 8 | PWM#2 |
| 9 | 24V | 10 | 24V |
| 11 | GND | 12 | GND |
| 13 | 12V | 14 | 12V |
| 15 | 12V | 16 | 24V |
| 17 | GND | 18 | GND |
| 19 | GND | 20 | GND |
| 21 | GND | 22 | L/DIM0_VS |
| 23 | L/DIM0_MOSI | 24 | L/DIM0_SCLK |

[LD42B models]



[LD42A models]



Checking order when there is no audio

① Check the contact condition of or 24V connector of Main Board

② Measure the 24V input voltage supplied from Power Board
(If there is no input voltage, remove and check the connector)

③ Connect the tester RX1 to the speaker terminal and if you hear the Chik Chik sound when you touch the GND and output terminal, the speaker is normal.


Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|----------------------------------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | D. Function error_ No response in remote controller, key error | Established date | 2014. 01 .20 | |
| | Content | Remote controller operation checking method | Revised date | | A27 |

[LD42B models]



[LD42A models]






| P4000 | |
|-------|---------------|
| 1 | GND |
| 2 | +3.5V_WOL |
| 3 | BT_RESET |
| 4 | WIFI_DM |
| 5 | NC |
| 6 | WIFI_DP |
| 7 | WIFI_POWER_ON |
| 8 | GND |
| 9 | EYE_SDA |
| 10 | GND |
| 11 | EYE_SCL |
| 12 | KEY1 |
| 13 | GND |
| 14 | KEY2 |
| 15 | IR |
| 16 | +3.5V_ST |
| 17 | LED_R |
| 18 | GND |

Checking order

1. Check IR cable condition between IR & Main board
2. Check the st-by 3.5V on the terminal 16.
4. When checking the Pre-Amp when the power is in ON condition, it is normal when the Analog Tester needle moves slowly, and defective when it does not move at all.

Standard Repair Process Detail Technical Manual

| | | | | | |
|--------|---------------|------------------------------------|------------------|--------------|-----|
| LCD TV | Error symptom | Display has error especially color | Established date | 2014. 01 .20 | |
| | Content | V-Com checking and adjust method | Revised date | | A28 |



Entry method

1. Press the ADJ button on the remote controller for adjustment.
2. Enter into V-Com of item 14.
3. Check and adjust V-Com value.

A28